

SEIKO


PARTS LIST

CW-1, CW-7B

CW-8BV

LCW-8B

LCW-8BV




SEIKO SEWING MACHINE CO., LTD.


INDEX

Page

Thread take up lever, needle bar for all models	1
天秤・針棒関係	
Arm shaft, feeding mechanism for CW.LCW-7, 8 & 8V	2
CW・LCW-7, 8 & 8V 上軸・送り機構関係	
Lifting lever, face plate, slide plate for all models	3
弓, 面板, 差し板, ベース関係	
Presser bar, lifting rock shaft, vibrating presser foot for CW.LCW-8, 8B, 8V & 8BV . . .	4
CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係	
Hook driving shaft, rotating hook, timing belt for all models	5
下軸, カマ関係	
Thread tension, feed driving rock shaft, feeder, needle plate for all models	6
糸掛, 糸調子, 送り竿関係	
Accessories	7
附属関係	
Reverse stitch mechanism for CW.LCW-7B, 8B & 8BV	8
CW・LCW-7B・8B&8BV バック関係	
Special parts for CW.LCW-8V & 8BV	9
CW・LCW-8V&8BV 専用部品	
Presser bar, needle bar, needle plate, feeder for CW.LCW-7 & 7B	10
CW・LCW-7 & 7B 針棒・押え棒関係	
Special parts for LCW	11
LCW 専用部品	
Special parts for CW-1	12
CW-1 専用部品	
Belt guard	13
ベルトガード	
Special parts for LCW-6F	14
LCW-6F 専用部品	
Feed mechanism for LCW-8B	15
LCW-8B 送り関係	




Model CW-8V



Model LCW-8B

THREAD TAKE UP LEVER, NEEDLE BAR, ETC. FOR ALL MODELS EXCEPT PARTS MARKED * . O . X . Δ



x N0122

Parts marked * are not necessary for CW-7 & 7B
 Parts marked O are not necessary for LCW
 Parts marked X are not necessary for CW-1
 Parts marked Δ are not necessary for LCW-6F


(*印は CW-7, CW-7B には不要)
 (O印は LCW タイプには不要)
 (X印は CW-1 には不要)
 (Δ印は LCW-6F には不要)

CW・LCW-7, 8 & 8V 上軸・送り機構関係

ARM SHAFT, FEEDING MECHANISM

FOR CW・LCW-7, 8 & 8V

2



LIFTING LEVER, FACE PLATE, SLIDE PLATE FOR ALL MODELS EXCEPT PARTS MARKED O.X.*

 10712

13056-A



13059



O 10707

10706



10705



13079


O 10699





Y O 10704

O O 10703

XO 10702



XO 10698



13436

13440


13440

O 10700


13027



13026




X 13009



13024





13025



1 1

13027

13089



13438

19403



13006



13388-A


13008




Parts marked * are not necessary for CW.LCW-8V & 8BV (*印は CW・LCW-8V & 8BV には不要)
 Parts marked O are not necessary for LCW (O印は LCW には不要)
 Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)

CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係
 PRESSER BAR, LIFTING ROCK SHAFT, VIBRATING PRESSER
 FOR CW・LCW-8, 8B, 8V & 8BV

4



HOOK DRIVING SHAFT, ROTATING HOOK, TIMING BELT FOR ALL MODELS EXCEPT PARTS MARKED * . + . - . x . Δ




Part marked * is not necessary for CW . LCW-7B . 8B & 8BV
Part marked + is for only CW . LCW-7B . 8B & 8BV
Part marked - is not necessary for CW . LCW-8V & 8BV
Parts marked X are not necessary for CW-1
Parts marked Δ is for only LCW-6F

(*印は CW・LCW-7B、8B&8BV には不要)
(+印は CW・LCW-7B、8B&8BV にのみ)
(-印は CW・LCW-8V&8BV には不要)
(X印は CW-1 には不要)
(Δ印は LCW-6F のみ)

THREAD TENSION, FEED DRIVING ROCK SHAFT, FEEDER, NEEDLE

PLATE FOR ALL MODELS EXCEPT PARTS MARKED *.+.O.X.Δ



Parts marked * are not necessary for CW, LCW-7, 7B, 8V & 8BV (*印は CW・LCW-7, 7B, 8V & 8BV には不要)
 Parts marked + are not necessary for CW, LCW-8V & 8BV (+印は CW・LCW-8V & 8BV には不要)
 Parts marked O are not necessary for LCW (O印は LCW には不要)
 Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)
 Parts marked Δ are not necessary for LCW-6F (Δ印は LCW-6F には不要)

ACCESSORIES FOR ALL MODELS



8132A

10656




8118



N0122
* N0618
N 0118

10748



35254

19473

8120


8121

19459



19458

19457

10734



8123
O 11193



50285



8125




10709

X
10942


8124



13098



13096



Part marked X is used for only CW-1

Part marked O is used for only LCW

Part marked * is used for only CW, LCW-7B, 8B & 8BV


(X印は CW-1 のみ)

(O印は LCW のみ)

(*印は CW, LCW-7B, 8B & 8BV のみ)

CW・LCW-7B・8B&8BV バック関係
 REVERSE STITCH MECHANISM FOR
 CW・LCW-7B, 8B & CW-8BV

8



13246



13249



13234



13235



11823




8086-02



13240



13221C



10561




13218



13217



12128C



13219




2067

13216



13235



13256

13243



13212




13213



2067

13252



13207



13208




13209




2067

13253




13206



10545



13204




8111

10659



13438



13263


11830




13261



13264




13260




CW・LCW-7 & 7B 針棒・押え棒関係
 PRESSER BAR, NEEDLE BAR, NEEDLE PLATE, FEEDER
 FOR CW・LCW-7 & 7B

10



LCW 専用部品
SPECIAL PARTS FOR LCW



Parts marked * is used for only LCW-7, 7B

Parts marked + is used for only LCW-8, 8V, 8B & 8BV

Parts marked Δ is not necessary for LCW-6F


(*印は LCW-7, 7B のみ)

(+印は LCW-8, 8V, 8B & 8BV のみ)

(Δ印は LCW-6F には不要)

CW-1 専用部品
SPECIAL PARTS FOR CW-1

12



NOTE) 13423 A ... Use with guard
B ... Use without guard 注) 13423


A ガード付用
B ガード無用

13


オプション品

Parts available at
extra charge

ベルトガード BELT GUARD




フィンガーガード
Finger guard



検出器支持棒
Synchronizer support rod




ベルトガードなし用
for Machine without Belt guard



ベルトガード用
for Machine with Belt guard

LCW - 6F 専用部品
SPECIAL PARTS FOR LCW - 6F

14



LCW-8B 送り関係

FEED MECHANISM FOR LCW - 8B

