

Singer 7-16

Singer 7-17

Singer 7-18

HISTORICAL COPY
Price List of Parts
DO NOT REMOVE

Numbers

7-16

7-17

7-18

MACHINES



The Singer Manufacturing Company.

INDEX.

| | PAGE |
|-------------------------|------|
| No. 7-16 Machine..... | 4 |
| No. 7-17 "..... | 10 |
| No. 7-18 "..... | 11 |
| Accessories..... | 9 |
| Belt Shifter..... | 11 |
| Bobbin Winder..... | 12 |
| Driving Attachment..... | 10 |
| Numerical List..... | 13 |

List of Parts

NUMBERS

7-16 to 7-18

MACHINES.

In ordering from this list, use **ONLY** the **PART** number, in the first column.

Each number always indicates the **SAME PART** in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only.
- D. Polished " "
- E. Soft, not Polished.

These letters **MUST BE USED** *when* they appear in the list, and **AFTER** the number, *as* in the list.

In this series

1 to 1500 are Screw Numbers.

1501 " 1800 " Nut " "

1801 " 2000 " Roller " "

2001 and upward are numbers of Machine Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are **NOT TO BE USED** in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

PARTS COMPLETE FOR

7-16 MACHINE.

**DROP FEED, $\frac{1}{4}$ -INCH STITCH, NO. 14 NEEDLE, FOR HEAVY THREAD,
FOR OIL PRESS BAGS, ETC.**

| No. | Plate. | Name. | Each. | Old No. |
|--------|--------|---|-------|---------|
| *19501 | — | Arm..... | 18 50 | — |
| 8702 | 887 | " Dowel Pin..... | 15 | 3 |
| 872E | 900 | " Screw..... | 10 | — |
| 11853 | 825 | " Shaft..... | 7 00 | 4 |
| 11354 | 830 | " " Bushing..... | 75 | 5 |
| 437C | 899 | " " " Set Screw..... | 04 | — |
| 11913 | 825 | " Side Cover..... | 25 | — |
| 65D | 899 | " " " Screw..... | 15 | — |
| 8708 | 827 | " Spool Pin..... | 05 | 72 |
| 11356 | 896 | Balance Wheel with two 354C..... | 1 75 | 6 |
| 354C | 899 | " " " Set Screw..... | 06 | — |
| *11359 | — | Bed..... | 18 50 | — |
| 11361 | 894 | " Foot Bracket (left)..... | 10 | — |
| 11360 | 894 | " " " (right)..... | 10 | — |
| 507E | 898 | " " " Bolt with 1515..... | 02 | — |
| 1515 | 890 | " " " " Nut..... | 01 | — |
| 670E | 862 | " Front Bearing Clamping Screw..... | 06 | — |
| 11363 | 825 | Crank Connecting Rod..... | 1 25 | 206 |
| *11364 | — | " " " Cap..... | — | — |
| 145E | 899 | " " " " Screw..... | 04 | — |
| 565C | 898 | " " " " Hinge Screw..... | 15 | — |
| 1513 | 890 | " " " " " " Nut..... | 05 | — |
| 11365 | 828 | Feed Bar..... | 1 50 | 25 |
| 307C | 898 | " " " " " " Screw Centre..... | 06 | — |
| 1513 | 890 | " " " " " " Nut..... | 05 | — |
| 11367 | 830 | " Cam with two 445C..... | 1 00 | 12 |
| 445C | 900 | " " " " " " Set Screw..... | 03 | — |
| 11368 | 830 | " Connecting Link..... | 35 | 16 |
| 565C | 898 | " " " " " " Hinge Screw..... | 15 | — |
| 1513 | 890 | " " " " " " Nut..... | 05 | — |
| 11884 | 875 | " Dog..... | 75 | — |
| 166D | 899 | " " Screw..... | 07 | — |
| 11370 | 825 | " Forked Connection..... | 1 75 | 207 |
| 565C | 898 | " " " " " " Hinge Scr..... | 15 | — |
| 1513 | 890 | " " " " " " Nut..... | 05 | — |
| 11371 | 825 | Feed Lifting Rock Shaft..... | 1 40 | 31 |
| 11372 | — | " " " " " " 11371 with..... | 2 35 | 29 |
| 11374 | 830 | Feed Lifting Rock Shaft Crank with..... | 95 | — |
| | | 453C and 1861..... | — | — |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|--|-------|---------|
| 2117 | 890 | Feed Lifting Rock Shaft Crank Pin..... | 01 | 23 |
| 1861 | 862 | " " " " " " Roller..... | 35 | — |
| 453C | 899 | Feed Lifting Rock Shaft Crank Set..... | 02 | — |
| 564C | 898 | Feed Lifting Rock Shaft Scr. Centre..... | 12 | — |
| 1508 | 800 | " " " " " " " Nut..... | 06 | — |
| 11375 | 830 | Feed Regulator..... | 60 | 208 |
| 568E | 898 | " " " " " " Hinge Screw..... | 15 | — |
| 254D | 902 | " " " " " " Thumb Screw..... | 40 | — |
| 11376 | 825 | " Rock Shaft..... | 1 40 | 21A |
| 11377 | — | " " " " " " 11376 with 11379..... | 2 00 | 20 |
| 11379 | 893 | " " " " " " Crank with 453C..... | 60 | 22 |
| 2117 | 890 | " " " " " " Pin..... | 01 | 23 |
| 453C | 899 | " " " " " " Set Screw..... | 02 | — |
| 564C | 898 | " " " " " " Screw Centre..... | 12 | — |
| 1508 | 890 | " " " " " " " Nut..... | 06 | — |
| 25881 | 894 | Guide..... | 40 | 34 |
| 254D | 902 | " Screw..... | 40 | — |
| 11402 | 828 | Lifting Presser Bar..... | 1 00 | 49 |
| 11461 | 851 | " " " " " " Bell Crank..... | 1 25 | 58 |
| 8D | 898 | " " " " " " Hinge..... | 20 | — |
| 1828 | 899 | Lifting Presser Bar Bell Crank Roller..... | 25 | — |
| 372C | 898 | Lifting Presser Bar Bell Crank Roller..... | 12 | — |
| 1518 | 800 | Lifting Presser Bar Bell Crank Roller..... | 04 | — |
| 2718 | 897 | Lifting Presser Bar Bell Crank Roller..... | 01 | 300 |
| 11463 | 851 | Lifting Presser Bar Guide Bracket..... | 2 00 | — |
| 159 | 899 | Lifting Presser Bar Guide Bracket..... | 03 | — |
| 11405 | 830 | Lifting Presser Bar Guide Bracket..... | 50 | 53 |
| 381D | 899 | Lifting Presser Bar Guide Bracket..... | 06 | — |
| 453C | 899 | Lifting Presser Bar Guide Bracket..... | 02 | — |
| 11465 | 853 | Lifting Presser Bar Spring Bracket..... | 1 00 | 51 |
| 353C | 899 | Lifting Presser Bar Spring Bracket..... | 12 | — |
| 11466 | 853 | Lifting Presser Bar Spring Bracket..... | 10 | — |
| 11726 | 848 | Needle Bar..... | 1 00 | — |
| 11381 | 830 | " " " " " " Connecting Link..... | 80 | 238 |
| 566C | 898 | " " " " " " Hinge..... | 15 | — |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|--|-------|---------|
| 1513 | 890 | Needle Bar Connecting Link Hinge Screw Nut..... | 05 | — |
| 11383 | 887 | Needle Bar Connecting Stud with two 445c..... | 1 25 | 36 |
| 445c | 900 | Needle Bar Connecting Stud Set Screw | 03 | — |
| 258D | 899 | " " Screw Bushing..... | 20 | — |
| 11847 | 888 | " " Clamp with 245 and 11385.... | 75 | — |
| 11385 | 890 | " " " " " " " " " " " " " " | 15 | 40 |
| 245 | 899 | " " " " " " " " " " " " " " | 03 | — |
| 11497 | — | Oil Cup..... | 80 | — |
| 11917 | — | " " " " " " " " " " " " " " | 25 | — |
| 9084 | 889 | " " " " " " " " " " " " " " | 02 | — |
| 2205 | 887 | " " " " " " " " " " " " " " | 04 | 296 |
| 207 | 901 | " " " " " " " " " " " " " " | 02 | — |
| 135D | 899 | " " " " " " " " " " " " " " | 05 | — |
| 11919 | 888 | " " " " " " " " " " " " " " | 05 | — |
| 8953 | — | " " " " " " " " " " " " " " | 03 | 297 |
| 5480 | 887 | " " " " " " " " " " " " " " | 01 | — |
| 11018 | 888 | Oil or Wax Stripper Washer (steel), for 11917..... | 03 | — |
| 207 | 901 | Oil or Wax Stripper Washer Screw.. | 02 | — |
| 11921 | 825 | " " Cup complete, Nos. 2205, 5480, 9084, 11497, 11917, 11918, 11919, two 8953 and three 207..... | 1 25 | — |
| 11841 | 827 | Oscillating Rock Shaft (steel)..... | 1 75 | — |
| 11398 | 827 | " " " " " " " " " " " " " " | 75 | 256 |
| 1508 | 890 | " " " " " " " " " " " " " " | 06 | — |
| 622c | 899 | " " " " " " " " " " " " " " | 15 | — |
| 1508 | 890 | Oscillating Rock Shaft Hinge Pin Scr. Bearing Nut..... | 06 | — |
| 11165 | 897 | Oscillating Rock Shaft Oil Pad..... | 01 | — |
| 11842 | — | " " " " " " " " " " " " " " | 2 75 | — |
| 11850 | 825 | Oscillating Shaft..... | 1 25 | — |
| 11393 | 887 | " " " " " " " " " " " " " " | 10 | 354 |
| 453c | 899 | " " " " " " " " " " " " " " | 02 | — |
| 11848 | — | " " " " " " " " " " " " " " | 30 | — |
| 11849 | 830 | " " " " " " " " " " " " " " | 75 | — |
| 2117 | 890 | Oscillating Shaft Crank Pin..... | 01 | 23 |
| 1885 | 900 | " " " " " " " " " " " " " " | 40 | — |
| 1513 | 890 | Oscillating Shaft Crank Roller and Screw Stud Nut..... | 05 | — |
| 190 | 899 | Oscillating Shaft Crank Roller Cap Screw..... | 03 | — |
| 5968 | 887 | Oscillating Shaft Crank Roller Cap Screw Washer..... | 02 | — |
| 453c | 899 | Oscillating Shaft Crank Set Screw... | 02 | — |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|---|-------|---------|
| 11908 | — | Presser Bar Lifter..... | 1 00 | — |
| 11909 | 830 | " " " " " " " " " " " " " " | 1 25 | — |
| 8760 | 888 | Presser Bar Lifter Friction Washer.. | 03 | 56 |
| 16D | 899 | " " " " " " " " " " " " " " | 20 | — |
| 8761 | 890 | " " " " " " " " " " " " " " | 05 | 55 |
| 11906 | 827 | " " " " " " " " " " " " " " | 50 | — |
| 353c | 899 | " " " " " " " " " " " " " " | 12 | — |
| 8763 | 890 | " " " " " " " " " " " " " " | 25 | 152 |
| 7958 | 890 | " " " " " " " " " " " " " " | 01 | 153 |
| 8765 | 890 | Presser Bar Lifting Link Hinge Stud Washer..... | 04 | 154 |
| 258D | 899 | Presser Bar Screw Bushing..... | 20 | — |
| 11409 | 827 | " " " " " " " " " " " " " " | 15 | 50 |
| 11411 | 887 | " " " " " " " " " " " " " " | 10 | — |
| 453c | 899 | " " " " " " " " " " " " " " | 02 | — |
| 252D | 898 | Pressure Regulating Thumb Screw.. | 40 | — |
| 11851 | 833 | Shuttle (cylinder), 3-in. diam., with 11910..... | 6 00 | — |
| 11910 | 833 | Shuttle Bobbin (solid and hardened). | 25 | — |
| 11852 | 833 | " " " " " " " " " " " " " " | 2 50 | — |
| 8961 | 833 | " " " " " " " " " " " " " " | 02 | 63 |
| 11853 | 833 | " " " " " " " " " " " " " " | 15 | — |
| 12002 | 833 | " " " " " " " " " " " " " " | 01 | — |
| 11854 | 833 | " " " " " " " " " " " " " " | 03 | — |
| 590E | 901 | " " " " " " " " " " " " " " | 02 | — |
| 11727 | — | " " " " " " " " " " " " " " | 1 25 | — |
| 2117 | 890 | " " " " " " " " " " " " " " | 01 | 23 |
| 453c | 899 | " " " " " " " " " " " " " " | 02 | — |
| 11855 | 833 | " " " " " " " " " " " " " " | 2 75 | — |
| 11832 | 830 | " " " " " " " " " " " " " " | 1 00 | — |
| 11833 | 889 | " " " " " " " " " " " " " " | 01 | — |
| 11834 | 830 | " " " " " " " " " " " " " " | 25 | — |
| 32D | 901 | " " " " " " " " " " " " " " | 15 | — |
| 11835 | — | " " " " " " " " " " " " " " | 2 75 | — |
| 11837 | 825 | " " " " " " " " " " " " " " | 2 00 | — |
| 11838 | 889 | " " " " " " " " " " " " " " | 03 | — |
| 11836 | 825 | " " " " " " " " " " " " " " | 4 00 | — |
| 135D | 899 | Shuttle Race Screw..... | 05 | — |
| 11500 | 851 | " " " " " " " " " " " " " " | 50 | — |
| 180 | 901 | " " " " " " " " " " " " " " | 03 | — |
| 11418 | 828 | " " " " " " " " " " " " " " | 35 | 318 |
| 773c | 901 | " " " " " " " " " " " " " " | 05 | — |
| 8964 | 833 | " " " " " " " " " " " " " " | 40 | 360 |
| 11421 | 887 | Tension Bracket..... | 50 | 76 |
| 190 | 899 | " " " " " " " " " " " " " " | 03 | — |
| 11423 | 888 | " " " " " " " " " " " " " " | 03 | 75 |
| 8879 | 887 | " " " " " " " " " " " " " " | 01 | — |

No. 171, No. 5 Machine.....

| No. | Plate | Name | Each. | Old No. |
|-------|-------|---|-------|---------|
| 1560 | 903 | Tension Regulating Thumb Nut..... | 04 | — |
| 8905 | 887 | “ “ “ “ | 01 | 361 |
| 411 | 898 | Washer..... | 25 | — |
| 11422 | 888 | Tension Screw Stud..... | 10 | 74 |
| 11044 | 897 | “ Spring..... | 75 | — |
| 11420 | — | “ Wheel..... | — | — |
| | | “ (wheel) complete, Nos. 411, 1560, 8905, 11044, 11422, 11423 and two 8879..... | 1 20 | — |
| 11950 | 888 | Thread Eyelet for 11041..... | 05 | — |
| 2102 | 888 | “ Retainer Disc..... | 05 | 84 |
| 1560 | 903 | “ “ Regulating Thumb Nut..... | 04 | — |
| 8905 | 887 | Thread Retainer Regulating Thumb Nut Washer..... | 01 | 361 |
| 686D | 902 | Thread Retainer Screw Stud..... | 25 | — |
| 2103 | 888 | “ “ Spring..... | 03 | 85 |
| 11041 | — | “ “ complete, Nos. 686D, 1560, 2103, 8905 and two 2102..... | 45 | — |
| 11428 | 827 | Thread Take-up Cam (steel), with 434C..... | 5 00 | 80 |
| 8873 | 887 | Thread Take-up Cam Pin..... | 05 | 81 |
| 434C | 899 | “ “ “ Set Screw..... | 04 | — |
| 11729 | — | “ “ Lever..... | 2 00 | — |
| 11730 | 848 | “ “ “ 11729 with 1518, 1845, 11731 to 11733 & 11735..... | 2 75 | — |
| 567D | 898 | Thread Take-up Lever Hinge Screw..... | 15 | — |
| 11731 | 875 | “ “ “ Roller..... | 25 | — |
| 1845 | 899 | “ “ “ “ and Scr. Stud..... | 30 | — |
| 1518 | 890 | Thread Take-up Lever Roller and Screw Stud Nut..... | 04 | — |
| 11732 | 875 | Thread Take-up Lever Roller Pin..... | 03 | — |
| 11733 | — | “ “ “ “ Plate (right)..... | 10 | — |
| 11734 | 875 | Thread Take-up Lever Roller Plate (left) obsolete..... | 10 | — |
| 11735 | — | Thread Take-up Lever Roller Plate Rivet..... | 01 | — |
| 11052 | 887 | Thread Take-up Spring..... | 08 | — |
| 11431 | 888 | “ “ “ Regulator Plate..... | 10 | 83 |
| 190 | 899 | Thread Take-up Spring Regulator Plate Adjusting Screw..... | 03 | — |
| 11736 | — | Throat Plate Body for 11737..... | 75 | — |
| 11737 | 875 | “ “ “ 11736, with 219 and 11738 or 11801..... | 1 00 | — |
| 11738 | 875 | Throat Plate Needle Plate (large ob-long needle hole)..... | 25 | — |
| 11801 | 875 | Throat Plate Needle Plate (small ob-long needle hole)..... | 25 | — |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|--|-------|---------|
| 219 | 901 | Throat Plate Needle Plate Screw..... | 02 | — |
| 381D | 899 | “ “ “ Screw..... | 06 | — |
| 11949 | 839 | Vibrating Presser Bar..... | 1 00 | — |
| 11468 | 851 | “ “ “ Guide Bracket..... | 1 30 | — |
| 11469 | — | “ “ “ “ “ “ “ “ 11468 with 11470 and two 190..... | 1 50 | 91 |
| 11470 | 851 | Vibrating Presser Bar Guide Bracket Cap..... | 20 | 92 |
| 190 | 899 | Vibrating Presser Bar Guide Bracket Cap Screw..... | 03 | — |
| 3012 | 853 | Vibrating Presser Bar Guide Bracket Pin..... | 01 | — |
| 448C | 900 | Vibrating Presser Bar Guide Bracket Set Screw..... | 03 | — |
| 164D | 899 | Vibrating Presser Bar Hinge Cap Scr. “ “ “ “ “ “ “ “ | 04 | — |
| 8800 | 890 | Washer..... | 06 | 90 |
| 11471 | 851 | Vibrating Presser Bar Spring..... | 05 | 93 |
| 11472 | 853 | “ “ “ “ “ Bracket..... | 10 | 94 |
| 231 | 901 | “ “ “ “ “ “ “ “ Screw..... | 03 | — |
| 19522 | 875 | Vibrating Presser Foot..... | 75 | — |
| 898D | 901 | “ “ “ “ “ Screw..... | 04 | — |
| 1547 | 903 | “ “ “ “ “ Nut..... | 03 | — |

ACCESSORIES.

| No. | Plate. | Name. | Each. | Old No. |
|-------|--------|--|-------|---------|
| 25957 | 895 | Oiler with 4½-in. spout. Old No. 570, A & A..... | 12 | — |
| 25958 | — | Oiler Spout, 4½ inches. Old No. 571, A. & A..... | 04 | — |
| 26026 | 895 | Screw Driver. Old No. 393, A. & A..... | 10 | — |
| 11831 | 895 | “ “ 5-in. blade..... | 20 | — |
| 8908 | 894 | Wrench for 354C..... | 10 | 351 |
| 8909 | 894 | “ “ 1518 and 1518..... | 15 | 352 |
| 8910 | 894 | “ “ 1508..... | 25 | — |

7-17 MACHINE.

DROP FEED, $\frac{1}{4}$ -INCH STITCH, No. 14 NEEDLE, FOR HEAVY THREAD
FOR OIL PRESS BAGS, ETC., SINGER DRIVING ATTACHMENT.

This Machine is Composed of the SAME PARTS as 7-16 Machine,
Excepting:

SINGER DRIVING ATTACHMENT.

| No. | Plate. | Name | Each. | Old No. |
|-------|--------|---|-------|---------|
| 11438 | 896 | Balance Wheel with two 354c. substituting 11356 | 3 75 | 190 |
| 8873 | 887 | Balance Wheel Pin | 05 | 81 |
| 3540 | 899 | " " Set Screw | 06 | — |
| 8984 | 827 | Brake Block (wood) | 05 | 198 |
| 9D | 898 | " " Screw | 20 | — |
| 11439 | — | Friction Pulley | 2 00 | 191 |
| 11440 | 896 | " " 11439 with 11441 | 2 25 | — |
| 11441 | 849 | " " Centre Plug | 25 | 193 |
| 11442 | 896 | " Washer | 10 | 192 |
| 401E | 899 | " " Screw | 02 | — |
| 11443 | 896 | Lever | 1 25 | 194 |
| 11444 | 896 | " Bracket | 85 | 196 |
| 497E | 900 | " " Bolt, $1\frac{1}{2} \times \frac{1}{2}$ -inch, with 1522 | 05 | — |
| 1522 | 903 | Lever Bracket Bolt Nut | 02 | — |
| 135D | 899 | " " Screw | 05 | — |
| 8991 | 828 | " " Washer | 06 | 197 |
| 8992 | 828 | " " Spring | 40 | 195 |
| 11864 | — | Shaft Driving Pulley (sectional), 10-inch diam., $1\frac{1}{2}$ -inch face, with two 597c. Old No. 294, P. T. F. | 75 | 202 |
| 5970 | 900 | Shaft Driving Pulley Clamping Screw | 08 | — |
| 2875 | 896 | Treadle | 30 | — |
| 2876 | — | " Connecting Rod (lower) | 05 | — |
| 2877 | — | " " " (upper) | 05 | — |
| 9079 | 895 | " " " Clamp with 354c. Old No. 75, P. T. F. | 12 | 201 |
| 354c | 899 | Treadle Connecting Rod Clamp Ser. | 06 | — |
| 2988 | 895 | " Connection, Nos. 2876, 2877 and 9079 | 22 | — |
| 2878 | 896 | Treadle Stand | 15 | — |
| 9082 | 890 | " " Cotter Pin. Old No. 72 P. T. F. | 01 | — |
| 12186 | — | Treadle 2875, with 2878 and 9082 | 45 | — |
| 15018 | — | " complete, Nos. 2988 and 12186 | 65 | — |
| 11436 | — | Singer Driving Attachment complete, Nos. 9D, 135D, 8873, 8984, 8991, 8992, 11438, 11440, 11442, 11443, 11444, 11864, 15018, two 497E and four 401E. Old No. 156, P. T. F. | 10 00 | — |

7-18 MACHINE.

DROP FEED, $\frac{1}{4}$ -INCH STITCH, No. 14 NEEDLE, FOR HEAVY THREAD,
FOR OIL PRESS BAGS, ETC., BELT SHIFTER.

This Machine is Composed of the SAME PARTS as 7-16 Machine
Excepting:

| No. | Plate. | Name | Each. | Old No. |
|-------|--------|-------------------------------|-------|---------|
| 11878 | 838 | Arm Shaft, substituting 11353 | 7 00 | — |

BELT SHIFTER.

| No. | Plate. | Name | Each. | Old No. |
|-------|--------|------------------------------------|-------|---------|
| 11446 | 890 | Cord Eyelet | 04 | 106 |
| 11447 | 874 | " Pulley | 35 | 107 |
| 567D | 898 | " " Screw | 15 | — |
| 5667 | — | Foot Lever | 15 | — |
| 5669 | — | " " Bracket | 10 | — |
| 6439 | — | " " Chain (length 36 to 45 inches) | 20 | — |

In ordering No. 6439 state length required.

| | | | | |
|-------|-----|--|------|-----|
| 5671 | 897 | Foot Lever Hinge Pin | 01 | — |
| 5672 | 895 | " " Lifting Spring | 08 | — |
| 5668 | 895 | " " 5667 with 5669 and 5671 | 40 | — |
| 11940 | 896 | Fork | 75 | — |
| 4340 | 899 | " Set Screw | 04 | — |
| 11941 | 895 | Frame with 8804 and two 4340 | 1 75 | — |
| 8804 | 892 | " Handle | 30 | 101 |
| 11450 | 828 | Guide Rod | 30 | 108 |
| 2117 | 890 | " " Pin | 01 | 23 |
| 11943 | 896 | Pulley (fast) with two 354c | 1 10 | — |
| 3540 | 899 | " " Set Screw | 06 | — |
| 11944 | 896 | " (loose) | 1 00 | — |
| 11459 | 897 | " " Collar with two 448c | 25 | 98 |
| 448c | 900 | " " " Set Screw | 03 | — |
| 11451 | 828 | Slide Rod | 75 | 102 |
| 11453 | 887 | " " Collar with two 448c | 25 | 103 |
| 448c | 900 | " " " Set Screw | 03 | — |
| 2117 | 890 | " " Pin | 01 | 23 |
| 11942 | 828 | " " Spring | 15 | — |
| 11453 | 887 | " " " Collar with two 448c | 25 | 103 |
| 448c | 900 | " " " Set Screw | 03 | — |
| 11945 | — | Belt Shifter complete, Nos. 567D, 5668, 5672, 6439, 11446, 11447, 11450, 11451, 11459, 11940 to 11944, two each 2117 and 11453 | 7 50 | — |

BOBBIN WINDER (HAND) FOR MACHINE BED.

| No. Plate | Name | Each | Old No. |
|-----------|---|------|---------|
| 11755 — | Belt..... | 05 | — |
| 11756 — | " 11755 with 25028 Old No. 101, | | |
| | No. 11 Machine..... | 05 | — |
| 25028 889 | Belt Hook..... | 01 | 371 |
| 135D 899 | Bobbin Winder Screw..... | 05 | — |
| 11758 858 | Frame. Old No. 101, No. 11 Mach.. | 50 | — |
| 11759 858 | Pulley. " " 103, " " " .. | 25 | — |
| 11760 892 | " Driving Wheel..... | 50 | 366 |
| 8380 893 | " " " Handle..... | 03 | — |
| 11762 893 | " " " Stud..... | 10 | — |
| 8382 887 | " " " " " .. | | |
| | Washer..... | 01 | — |
| 11761 — | Pulley Driving Wheel Handle com- plete, Nos. 8380, 8382 and 11762... | 10 | 369 |
| 11763 887 | Pulley Driving Wheel Stud..... | 10 | 367 |
| 2260 889 | " " " " Pin..... | 01 | 153 |
| 11764 888 | " " " " Washer..... | 01 | 368 |
| 11765 858 | Spindle. Old No. 102, No. 11 Mach. | 40 | — |
| 11754 855 | Bobbin Winder complete, Nos. 2269, 11756, 11758, 11759, 11760, 11761, 11763, 11764 and 11765. Old No. 100, No. 11 Machine..... | 2 00 | — |

Numerical List of Parts.

| No. Plate | Name | Each. | Old No. |
|-----------|---|-------|---------|
| 8D 898 | Lifting Presser Bar Bell Crank Hinge Screw..... | 20 | — |
| 9D 898 | Brake Block Screw for 11436..... | 20 | — |
| 16D 899 | Presser Bar Lifter Hinge Screw..... | 20 | — |
| 32D 901 | Shuttle Race Back Spring Screw ... | 15 | — |
| 65D 899 | Arm Side Cover Screw..... | 15 | — |
| 135D 899 | Lever Bracket Screw for 11436..... | 05 | — |
| 135D 899 | Oil Cup Screw..... | 05 | — |
| 135D 899 | Shuttle Race Screw..... | 05 | — |
| 135D 899 | Bobbin Winder Screw for 11754..... | 05 | — |
| 145E 899 | Crank Connecting Rod Cap Screw.... | 04 | — |
| 150 899 | Lifting Presser Bar Guide Bracket Adjusting Screw..... | 03 | — |
| 164D 899 | Vibrating Presser Bar Hinge Cap Screw..... | 04 | — |
| 166D 899 | Feed Dog Screw..... | 07 | — |
| 180 901 | Shuttle Race Slide (back) Screw.... | 03 | — |
| 190 899 | Oscillating Shaft Crank Roller Cap Screw..... | 03 | — |
| 190 899 | Tension Bracket Screw..... | 03 | — |
| 190 899 | Thread Take-up Spring Regulator Plate Adjusting Screw..... | 03 | — |
| 190 899 | Vibrating Presser Bar Guide Bracket Cap Screw..... | 03 | — |
| 207 901 | Oil Cup Cover Latch Spring Screw.. | 02 | — |
| 207 901 | " or Wax Stripper Washer Screw.. | 02 | — |
| 219 901 | Throat Plate Needle Plate Screw.... | 02 | — |
| 231 901 | Vibrating Presser Bar Spring Bracket Screw..... | 03 | — |
| 245 899 | Needle Clamp Set Screw..... | 03 | — |
| 252D 898 | Pressure Regulating Thumb Screw.. | 40 | — |
| 254D 902 | Feed Regulator Thumb Screw..... | 40 | — |
| 254D 902 | Guide Screw..... | 40 | — |
| 258D 899 | Needle Bar Screw Bushing..... | 20 | — |
| 258D 899 | Presser " " " .. | 20 | — |
| 307G 898 | Feed Bar Screw Centre..... | 06 | — |
| 353C 899 | Lifting Presser Bar Spring Bracket Set Screw..... | 12 | — |
| 353C 899 | Presser Bar Lifting Link Cap Screw.. | 12 | — |
| 354G 899 | Balance Wheel Set Screw for 11356 and 11438..... | 06 | — |
| 354G 899 | Belt Shifter Pulley (fast) Set Screw.. | 06 | — |
| 354G 899 | Treadle Connecting Rod Clamp Ser for 9079..... | 06 | — |
| 372C 898 | Lifting Presser Bar Bell Crank Roller Screw..... | 12 | — |
| 381D 899 | Lifting Presser Bar Guide Bracket Guide Screw..... | 06 | — |

| No. | Plate | Name | Each. | Old No. |
|------|-------|--|-------|---------|
| 381D | 899 | Throat Plate Screw | 06 | — |
| 401E | 899 | Friction Washer Screw for 11436.... | 02 | — |
| 411 | 898 | Tension Screw Stud | 25 | — |
| 434C | 899 | Belt Shifter Fork Set Screw for 11945 | 04 | — |
| 434C | 899 | Thread Take-up Cam Set Screw..... | 04 | — |
| 437C | 899 | Arm Shaft Bushing Set Screw | 04 | — |
| 445C | 900 | Feed Cam Set Screw | 03 | — |
| 445C | 900 | Needle Bar Connecting Stud Set Ser. | 03 | — |
| 448C | 900 | Belt Shifter Pulley (loose) Collar Set Screw..... | 03 | — |
| 448C | 900 | Belt Shifter Slide Rod Collar Set Ser | 03 | — |
| 448C | 900 | " " " " Spring Collar Set Screw..... | 03 | — |
| 448C | 900 | Vibrating Presser Bar Guide Bracket Set Screw..... | 03 | — |
| 453C | 899 | Feed Lifting Rock Shaft Crank Set Screw..... | 02 | — |
| 453C | 899 | Feed Rock Shaft Crank Set Screw .. | 02 | — |
| 453C | 899 | Lifting Presser Bar Guide Bracket Set Screw..... | 02 | — |
| 453C | 899 | Oscillating Shaft Collar Set Screw... | 02 | — |
| 453C | 899 | " " Crank Set Screw... | 02 | — |
| 453C | 899 | Presser Bar Spring Collar Set Screw. | 02 | — |
| 453C | 899 | Shuttle Driver Set Screw..... | 02 | — |
| 497E | 900 | Lever Bracket Bolt. $1\frac{1}{2} \times \frac{1}{2}$ -in., with 1522, for 11436..... | 05 | — |
| 507E | 898 | Bed Foot Bracket Bolt with 1515 ... | 02 | — |
| 564C | 898 | Feed Lifting Shaft Rock Ser. Centre. | 12 | — |
| 564C | 898 | Feed Rock Shaft Screw Centre..... | 12 | — |
| 565C | 898 | Crank Connecting Rod Hinge Screw. | 15 | — |
| 565C | 898 | Feed Connecting Link " " | 15 | — |
| 565C | 898 | " Forked Connection " " | 15 | — |
| 566C | 898 | Needle Bar Connecting Link Hinge Screw..... | 15 | — |
| 567D | 898 | Belt Shifter Cord Pulley Ser. for 11945 | 15 | — |
| 567D | 898 | Thread Take-up Lever Hinge Screw. | 15 | — |
| 568E | 898 | Feed Regulator Hinge Screw | 15 | — |
| 590E | 901 | Shuttle Cylinder Latch Spring Screw | 02 | — |
| 597C | 900 | Shaft Driving Pulley Clamping Screw for 11884..... | 08 | — |
| 622C | 899 | Oscillating Rock Shaft Hinge Pin Screw Bearing..... | 15 | — |
| 670E | 893 | Bed Front Bearing Clamping Screw | 06 | — |
| 686D | 902 | Thread Retainer Screw Stud..... | 25 | — |
| 773C | 901 | Shuttle Tension Regulating Screw... | 05 | — |
| 872E | 900 | Arm Screw | 10 | — |
| 898D | 901 | Vibrating Presser Foot Screw..... | 04 | — |
| 1508 | 890 | Feed Lifting Rock Shaft Ser. Centre Nut..... | 06 | — |
| 1508 | 890 | Feed Rock Shaft Screw Centre Nut. | 06 | — |

| No. | Plate | Name | Each. | Old No. |
|------|-------|--|-------|---------|
| 1508 | 890 | Oscillating Rock Shaft Hinge Pin Nut | 06 | — |
| 1508 | 890 | " " " " " Ser. | | |
| | | Bearing Nut..... | 06 | — |
| 1513 | 890 | Crank Connecting Rod Hinge Ser. Nut | 05 | — |
| 1513 | 890 | Feed Bar Screw Centre Nut..... | 05 | — |
| 1513 | 890 | " Connecting Link Hinge Ser. Nut | 05 | — |
| 1513 | 890 | " Forked Connection Hinge Screw Nut..... | 05 | — |
| 1513 | 890 | Needle Bar Connecting Link Hinge Screw Nut. | 05 | — |
| 1513 | 890 | Oscillating Shaft Crank Roller and Screw Stud Nut | 05 | — |
| 1515 | 890 | Bed Foot Bracket Bolt Nut..... | 01 | — |
| 1518 | 890 | Lifting Presser Bar Bell Crank Roller Screw Nut | 04 | — |
| 1518 | 890 | Thread Take-up Lever Roller and Screw Stud Nut..... | 04 | — |
| 1522 | 903 | Lever Bracket Bolt Nut for 497E.... | 02 | — |
| 1547 | 903 | Vibrating Presser Foot Screw Nut .. | 03 | — |
| 1560 | 903 | Tension Regulating Thumb Nut. | 04 | — |
| 1560 | 903 | Thread Retainer Regulating Thumb Nut | 04 | — |
| 1828 | 890 | Lifting Presser Bar Bell Crank Roller and Screw 372C | 25 | — |
| 1845 | 899 | Thread Take-up Lever Roller and Screw Stud..... | 30 | — |
| 1861 | 862 | Feed Lifting Rock Shaft Crank Roller and Stud | 35 | — |
| 1885 | 900 | Oscillating Shaft Crank Roller and Screw Stud..... | 40 | — |
| 2102 | 888 | Thread Retainer Disc..... | 05 | 84 |
| 2103 | 888 | " " Spring | 03 | 85 |
| 2117 | 890 | Belt Shifter Guide Rod Pin for 11945 | 01 | 23 |
| 2117 | 890 | " " Slide " " " " | 01 | 23 |
| 2117 | 890 | Feed Lifting Rock Shaft Crank Pin. | 01 | 23 |
| 2117 | 890 | " Rock Shaft Crank Pin | 01 | 23 |
| 2117 | 890 | Oscillating Shaft Crank Pin..... | 01 | 23 |
| 2117 | 890 | Shuttle Driver Pin..... | 01 | 23 |
| 2205 | 887 | Oil Cup Cover Latch Spring..... | 04 | 296 |
| 2269 | 889 | Bobbin Winder Pulley Driving Wheel Stud Pin for 11754..... | 01 | 153 |
| 2718 | 897 | Lifting Presser Bar Bell Crank Roller Screw Nut Washer..... | 01 | 309 |
| 2875 | 896 | Treadle for 12186. | 30 | — |
| 2876 | — | " Connecting Rod (lower) for 2988..... | 05 | — |
| 2877 | — | Treadle Connecting Rod (upper) for 2988 | 05 | — |
| 2878 | 896 | Treadle Stand for 12186..... | 15 | — |
| 2988 | 895 | " Connection, Nos. 2876, 2877 and 9079, for 15018..... | 22 | — |

| No. | Plate. | Name | Each | Old No. |
|------|--------|---|------|---------|
| 3012 | 853 | Vibrating Presser Bar Guide Bracket Pin..... | 01 | — |
| 5480 | 887 | Oil or Wax Stripper Washer (steel), for 11497..... | 01 | — |
| 5667 | — | Belt Shifter Foot Lever for 5668..... | 15 | — |
| 5668 | 895 | " " " " 5667 with 5669 and 5671, for 11945..... | 40 | — |
| 5669 | — | Belt Shifter Foot Lever Bracket for 5668..... | 10 | — |
| 5671 | 897 | Belt Shifter Foot Lever Hinge Pin for 5668..... | 01 | — |
| 5672 | 895 | Belt Shifter Foot Lever Lifting Spring for 11945..... | 03 | — |
| 5668 | 887 | Oscillating Shaft Crank Roller Cap Screw Washer..... | 02 | — |
| 6430 | — | Belt Shifter Foot Lever Chain (length 36 to 45 inches) for 11945..... | 20 | — |
| 7058 | 890 | Presser Bar Lifting Link Hinge Stud Pin..... | 01 | 153 |
| 8380 | 893 | Bobbin Winder Pulley Driving Wheel Handle for 11761..... | 03 | — |
| 8382 | 887 | Bobbin Winder Pulley Driving Wheel Handle Stud Washer for 11761..... | 01 | — |
| 8702 | 887 | Arm Dowel Pin..... | 15 | 3 |
| 8708 | 827 | " Spool Pin..... | 05 | 72 |
| 8760 | 888 | Presser Bar Lifter Friction Washer.. | 03 | 56 |
| 8761 | 890 | " " " Stop Pin..... | 05 | 55 |
| 8763 | 890 | " " " Lifting Link Hinge Stud | 25 | 152 |
| 8765 | 890 | " " " " " " Washer..... | 04 | 154 |
| 8800 | 890 | Vibrating Presser Bar Hinge Cap Screw Washer..... | 06 | 90 |
| 8804 | 892 | Belt Shifter Frame Handle for 11941..... | 30 | 101 |
| 8873 | 887 | Thread Take-up Cam Pin..... | 05 | 81 |
| 8873 | 887 | Balance Wheel Pin for 11436..... | 05 | 81 |
| 8879 | 887 | Tension Friction Washer (felt). Old No. 171, No. 5 Machine..... | 01 | — |
| 8905 | 887 | Tension Regulating Thumb Nut Washer..... | 01 | 361 |
| 8905 | 887 | Thread Retainer Regulating Thumb Nut Washer..... | 01 | 361 |
| 8908 | 894 | Wrench for 354c..... | 10 | 351 |
| 8909 | 894 | " " 1513 and 1518..... | 15 | 352 |
| 8910 | 894 | " " 1508..... | 25 | — |
| 8953 | — | Oil or Wax Stripper (felt). | 03 | 297 |
| 8961 | 833 | Shuttle Cylinder Hinge Pin..... | 02 | 63 |
| 8964 | 833 | " Tension Spring..... | 40 | 360 |
| 8984 | 827 | Brake Block (wood) for 11436..... | 05 | 198 |
| 8991 | 828 | Lever Bracket Washer for 11436..... | 06 | 197 |
| 8992 | 828 | " Spring for 11436..... | 40 | 195 |

| No. | Plate | Name | Each. | Old No. |
|--------|-------|---|-------|---------|
| 9079 | 895 | Treadle Connecting Rod Clamp with 354c for 2988. Old No. 75, P. T. F. | 12 | 201 |
| 9082 | 890 | Treadle Stand Cotter Pin for 12186. Old No. 72, P. T. F..... | 01 | — |
| 9084 | 889 | Oil Cup Cover Hinge Pin..... | 02 | — |
| 11041 | — | Thread Retainer complete, Nos. 686b, 1560, 2103, 8905 and two 2102..... | 45 | — |
| 11044 | 897 | Tension Wheel..... | 75 | — |
| 11052 | 887 | Thread Take-up Spring..... | 08 | — |
| 11165 | 897 | Oscillating Rock Shaft Oil Pad..... | 01 | — |
| 11353 | 825 | Arm Shaft..... | 7 00 | 4 |
| 11354 | 830 | " " Bushing..... | 75 | 5 |
| 11356 | 896 | Balance Wheel with two 354c..... | 1 75 | 6 |
| *11359 | — | Bed..... | 18 50 | — |
| 11360 | 894 | " Foot Bracket (right)..... | 10 | — |
| 11361 | 894 | " " " (left)..... | 10 | — |
| 11363 | 825 | Crank Connecting Rod..... | 1 25 | 206 |
| *11364 | — | " " " Cap..... | — | — |
| 11365 | 828 | Feed Bar..... | 1 50 | 25 |
| 11367 | 830 | " Cam with two 445c..... | 1 00 | 12 |
| 11368 | 830 | " Connecting Link..... | 35 | 16 |
| 11370 | 825 | " Forked Connection..... | 1 75 | 207 |
| 11371 | 825 | " Lifting Rock Shaft..... | 1 40 | 31 |
| 11372 | — | " " " " 11371 with 11374..... | 2 35 | 29 |
| 11374 | 830 | Feed Lifting Rock Shaft Crank with 453c and 1861..... | 95 | — |
| 11375 | 830 | Feed Regulator..... | 60 | 208 |
| 11376 | 825 | " Rock Shaft..... | 1 40 | 21A |
| 11377 | — | " " " 11376 with 11379..... | 2 00 | 20 |
| 11379 | 803 | " " " Crank with 453c..... | 60 | 22 |
| 11381 | 830 | Needle Bar Connecting Link..... | 80 | 238 |
| 11383 | 887 | " " " Stud with two 445c..... | 1 25 | 36 |
| 11385 | 890 | Needle Clamp Gib..... | 15 | 40 |
| 11393 | 887 | Oscillating Shaft Collar with two 453c..... | 10 | 354 |
| 11398 | 827 | " Rock Shaft Hinge Pin..... | 75 | 256 |
| 11402 | 828 | Lifting Presser Bar..... | 1 00 | 49 |
| 11405 | 830 | " " " Guide Bracket Guide..... | 50 | 53 |
| 11409 | 827 | Presser Bar Spring..... | 15 | 50 |
| 11411 | 887 | " " " Collar with 453c..... | 10 | — |
| 11418 | 828 | Shuttle Race Slide (front)..... | 35 | 318 |
| 11420 | — | Tension (wheel) complete, Nos. 411, 1560, 8905, 11044, 11422, 11423 and two 8879..... | 1 20 | — |
| 11421 | 887 | Tension Bracket..... | 50 | 76 |
| 11422 | 888 | " Spring..... | 10 | 74 |
| 11423 | 888 | " Friction Washer (steel)..... | 03 | 75 |
| 11428 | 827 | Thread Take-up Cam (steel) with 434c..... | 5 00 | 80 |
| 11431 | 888 | " " Spring Regulator Plate..... | 10 | 83 |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|--|-------|---------|
| 11436 | — | Singer Driving Attachment complete, Nos. 9D, 135D, 8873, 8984, 8991, 8992, 11438, 11440, 11442, 11443, 11444, 11864, 15018, two 497E and four 401E. Old No 156, P. T. F. | 10 00 | — |
| 11438 | 896 | Balance Wheel with two 354c, for 11436..... | 3 75 | 190 |
| 11439 | — | Friction Pulley for 11440 | 2 00 | 191 |
| 11440 | 896 | " " " 11439 with 11441 for 11436 | 2 25 | — |
| 11441 | 849 | Friction Pulley Centre Plug for 11440 | 25 | 193 |
| 11442 | 896 | " " Washer for 11436..... | 10 | 192 |
| 11443 | 896 | Lever for 11436..... | 1 25 | 194 |
| 11444 | 896 | " Bracket for 11436 | 85 | 196 |
| 11446 | 890 | Belt Shifter Cord Eyelet for 11945..... | 04 | 106 |
| 11447 | 874 | " " " Pulley " " | 35 | 107 |
| 11450 | 828 | " " Guide Rod " " | 30 | 108 |
| 11451 | 828 | " " Slide " " " | 75 | 102 |
| 11453 | 887 | " " " " Collar with two 448c, for 11945..... | 25 | 103 |
| 11453 | 887 | Belt Shifter Slide Rod Spring Collar with two 448c, for 11945..... | 25 | 103 |
| 11459 | 897 | Belt Shifter Pulley (loose) Collar with two 448c, for 11945..... | 25 | 98 |
| 11461 | 851 | Lifting Presser Bar Bell Crank..... | 1 25 | 58 |
| 11463 | 851 | " " " Guide Bracket with 159 and 453c | 2 00 | — |
| 11465 | 853 | Lifting Presser Bar Spring Bracket with 353c..... | 1 00 | 51 |
| 11466 | 853 | Lifting Presser Bar Spring Bracket Set Screw Washer..... | 10 | — |
| 11468 | 851 | Vibrating Presser Bar Guide Bracket | 1 30 | — |
| 11469 | — | " " " " " " 11468 with 11470 and two 190 | 1 50 | 91 |
| 11470 | 851 | Vibrating Presser Bar Guide Bracket Cap | 20 | 92 |
| 11471 | 851 | Vibrating Presser Bar Spring..... | 05 | 93 |
| 11472 | 853 | " " " " Bracket | 10 | 94 |
| 11497 | — | Oil Cup..... | 80 | — |
| 11500 | 851 | Shuttle Race Slide (back) | 50 | — |
| 11726 | 848 | Needle Bar | 1 00 | — |
| 11727 | — | Shuttle Driver with 453c..... | 1 25 | — |
| 11729 | — | Thread Take-up Lever..... | 2 00 | — |
| 11730 | 848 | " " " 11729 with 1518, 1845, 11731 to 11733 and 11735..... | 2 75 | — |
| 11731 | 875 | Thread Take-up Lever Roller..... | 25 | — |
| 11732 | 875 | " " " " Pin..... | 03 | — |
| 11733 | — | " " " " Plate (right)..... | 10 | — |
| 11734 | 875 | Thread Take-up Lever Roller Plate (left) obsolete..... | 10 | — |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|---|-------|---------|
| 11735 | — | Thread Take-up Lever Roller Plate Rivet | 01 | — |
| 11736 | — | Throat Plate Body for 11737..... | 75 | — |
| 11737 | 875 | " " " 11736 with 219 and 11738 or 11891..... | 1 00 | — |
| 11738 | 875 | Throat Plate Needle Plate (large oblong needle hole) | 25 | — |
| 11754 | 855 | Bobbin Winder (Hand, for Machine Bed) complete, Nos. 2269, 11756, 11758, 11759, 11760, 11761, 11763, 11764 and 11765. Old No. 100, No. 11 Machine | 2 00 | — |
| 11755 | — | Bobbin Winder Belt for 11756..... | 05 | — |
| 11756 | — | " " " 11755 with 25028, for 11754. Old No. 104, No. 11 Machine | 05 | — |
| 11758 | 858 | Bobbin Winder Frame for 11754. Old No. 101, No. 11 Machine..... | 50 | — |
| 11759 | 858 | Bobbin Winder Pulley for 11754. Old No. 103, No. 11 Machine..... | 25 | — |
| 11760 | 892 | Bobbin Winder Pulley Driving Wheel for 11754..... | 50 | 366 |
| 11761 | 859 | Bobbin Winder Pulley Driving Wheel Handle complete, Nos. 8380, 8382 and 11762..... | 10 | 369 |
| 11762 | 893 | Bobbin Winder Pulley Driving Wheel Handle Stud for 11761..... | 10 | — |
| 11763 | 887 | Bobbin Winder Pulley Driving Wheel Stud for 11754..... | 10 | 367 |
| 11764 | 888 | Bobbin Winder Pulley Driving Wheel Stud Washer for 11754..... | 01 | 368 |
| 11765 | 858 | Bobbin Winder Spindle for 11754. Old No. 102, No. 11 Machine..... | 40 | — |
| 11831 | 895 | Screw Driver, 5-in. blade | 20 | — |
| 11832 | 830 | Shuttle Race Back | 1 00 | — |
| 11833 | 889 | " " " Dowel Pin..... | 01 | — |
| 11834 | 830 | " " " Spring..... | 25 | — |
| 11835 | — | " " Body | 2 75 | — |
| 11836 | 825 | " " complete, Nos. 32D, 11832, 11834, 11835 and two 11833..... | 4 00 | — |
| 11837 | 825 | Shuttle Race Frame with 11838 | 2 00 | — |
| 11838 | 889 | " " " Position Pin..... | 03 | — |
| 11841 | 827 | Oscillating Rock Shaft (steel)..... | 1 75 | — |
| 11842 | — | " " " 11841 with 622c, 11165, 11398 and two 1508..... | 2 75 | — |
| 11847 | 888 | Needle Clamp with 245 and 11885..... | 75 | — |
| 11848 | — | Oscillating Shaft Crank..... | 30 | — |
| 11849 | 830 | " " " 11848 with 453c, 1513 and 1885..... | 75 | — |
| 11850 | 825 | Oscillating Shaft..... | 1 25 | — |

| No. | Plate | Name | Each. | Old No. |
|---------|-------|--|-------|---------|
| 11851 | 833 | Shuttle (cylinder), 3-in. diam., with 11910 | 6 00 | — |
| 11852 | 833 | Shuttle Cylinder..... | 2 50 | — |
| 11853 | 833 | " " Latch..... | 15 | — |
| 11854 | 833 | " " " Spring..... | 03 | — |
| 11855 | 833 | " " Frame | 2 75 | — |
| 11864 | — | Shaft Driving Pulley (sectional), 10-inch diam., 1½-inch face, with two 597c for 11436. Old No. 294, P. T. F. | 75 | 202 |
| 11878 | 838 | Arm Shaft for No. 7-18 Machine.... | 7 00 | — |
| 11884 | 875 | Feed Dog..... | 75 | — |
| 11891 | 875 | Throat Plate Needle Plate (small oblong needle hole)..... | 25 | — |
| 11906 | 827 | Presser Bar Lifting Link | 50 | — |
| 11908 | — | " " Lifter..... | 1 00 | — |
| 11909 | 830 | " " " 11908 with 8761 and 8763. | 1 25 | — |
| 11910 | 833 | Shuttle Bobbin (solid and hardened). | 25 | — |
| 11913 | 825 | Arm Side Cover..... | 25 | — |
| 11917 | — | Oil Cup Cover..... | 25 | — |
| 11918 | 888 | " or Wax Stripper Washer (steel) for 11917..... | 03 | — |
| 11919 | 888 | Oil Cup Thread Eyelet..... | 05 | — |
| 11921 | 825 | " " complete, Nos. 2205, 5480, 9084, 11497, 11917, 11918, 11919, two 8953 and three 207..... | 1 25 | — |
| 11940 | 896 | Belt Shifter Fork for 11945..... | 75 | — |
| 11941 | 896 | " " Frame with 8804 and two 434c, for 11945..... | 1 75 | — |
| 11942 | 828 | Belt Shifter Slide Rod Spring for 11945 | 15 | — |
| 11943 | 896 | " " Pulley (fast) with two 354c for 11945..... | 1 10 | — |
| 11944 | 896 | Belt Shifter Pulley (loose) for 11945. | 1 00 | — |
| 11945 | — | " " complete, Nos. 567D, 5668, 5672, 6439, 11446, 11447, 11450, 11451, 11459, 11940 to 11944, two each 2117 and 11453..... | 7 50 | — |
| 11949 | 839 | Vibrating Presser Bar..... | 1 00 | — |
| 11950 | 888 | Thread Eyelet for 11041..... | 05 | — |
| 12002 | 833 | Shuttle Cylinder Latch Pin..... | 01 | — |
| 12186 | — | Treadle 2875 with 2878 and 9082 for 15018..... | 45 | — |
| 15018 | — | Treadle complete, Nos. 2988 and 12186, for 11436 | 65 | — |
| * 19501 | — | Arm..... | 18 50 | — |
| 19522 | 875 | Vibrating Presser Foot | 75 | — |
| 25028 | 889 | Bobbin Winder Belt Hook..... | 01 | 371 |
| 25881 | 894 | Guide | 40 | 34 |

| No. | Plate | Name | Each. | Old No. |
|-------|-------|---|-------|---------|
| 25957 | 895 | Oiler with 4½-in. spout. Old No. 570, A. & A..... | 12 | — |
| 25958 | — | Oiler Spout, 4½ inches. Old No. 571, A. & A..... | 04 | — |
| 26026 | 895 | Screw Driver. Old No. 393, A. & A. | 10 | — |

THE SINGER MANUFACTURING COMPANY use and recommend exclusively the **WILLIMANTIC SPOOL COTTON.**

PLATE 825—ONE-FOURTH SIZE




PLATE 827—ONE-HALF SIZE




PLATE 828—ONE-HALF SIZE




PLATE 830—ONE-HALF SIZE




PLATE 833—FULL SIZE




PLATE 838—ONE-FOURTH SIZE




PLATE 839—ONE-HALF SIZE




PLATE 848—ONE-HALF SIZE




PLATE 849—FULL SIZE




PLATE 851—ONE-HALF SIZE




PLATE 853—FULL SIZE




PLATE 855—ONE-FOURTH SIZE




PLATE 858—ONE-HALF SIZE




PLATE 859—ONE-HALF SIZE




PLATE 862—FULL SIZE




PLATE 874—FULL SIZE




PLATE 875—FULL SIZE




PLATE 887—FULL SIZE




PLATE 888—FULL SIZE




PLATE 889—FULL SIZE




PLATE 890—FULL SIZE




PLATE 892—ONE-HALF SIZE




PLATE 893—FULL SIZE




PLATE 894—ONE-HALF SIZE




PLATE 895—ONE-HALF SIZE




PLATE 896—ONE-EIGHTH SIZE




PLATE 897—FULL SIZE




PLATE 898—FULL SIZE




PLATE 899—FULL SIZE




PLATE 900—FULL SIZE




PLATE 901—FULL SIZE




PLATE 902—FULL SIZE




PLATE 903—FULL SIZE

