Singer 17-32

Form 19012 (936) Printed in U.S.A.

LIST of PARTS



SINGER"

MACHINE No. 17-32

THE SINGER MANUFACTURING COMPANY

** A Trade Mark of THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling and when in continuous use, "TYPE B" or "TYPE D" OIL, sold by Singer Sewing Machine Company, should be applied at least twice each day to all oil holes marked "OIL", as instructed in Form 7946.

"TYPE D" OIL should be used when an oil is desired which will produce a minimum of stain on fabrics, even after a long period of storage.

Apply a few drops of oil to the shuttle bearings in the shuttle race each time a bobbin is replaced.

Copyright, U. S. A., 1935 and 1936, by The Singer Manufacturing Company All Rights Reserved for all Countries

INDEX

		Pa	ge
	Accessories	•	11
1	Bobbin Winders	•	11
	Foot Lifter Parts	•	13
	Knee Lifter Parts	•	13
	Machine Base	••	11
	Machine No. 17-32		E
	Numerical List of Parts		15
	Thread Unwinder		14

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed

B-Polished, Nickel Plated and Buffed

C-Hardened Only

D-Polished Only

E-Soft, Not Polished

F-Hardened and Polished

F.J-Hardened, Polished and Nickel Plated

G-Bright Rumbled and Nickel Plated

H-Blued

J-Nickel Plated Only

K-Hardened and Nickel Plated

L-Brass Plated

M-0xidized

N-Japanned, Dull

P-Japanned, Bright

R-Merlized

T-Copper Plated

T.A-Hardened, Polished, Copper and Nickel Plated and Buffed

T.B-Copper and Nickel Plated and Polished

T.J-Copper and Nickel Plated Only

T.K-Hardened, Copper and Nickel Plated

T.M-Copper Plated and Oxidized

T.L-Copper and Brass Plated

U-Zinc Plated

V-Silver Plated

W-Polished and Nickel Plated

Y-Black Nickel Plated Only

Z-Chromium Plated

Z.B-Polished, Nickel Plated, Buffed and Chromium Plated

Z.J-Nickel and Chromium Plated

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142000 are Screw Numbers

1501 to 1800 and 51501 to 51800 are Nut Numbers 1801 to 2000 and 51801 to 52000 are Roller Numbers 2001 to 50000 and 52001 to 140000 and 142001 to

190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

LIST OF PARTS COMPLETE

SINGER

MACHINE No. 17-32

For Pumps, Eyelet Ties, Blucher Oxfords, Etc. Has Horizontal Under Trimmer, Cylinder Bed 2 7/16 inches diameter, Drop Feed Across Arm and Roller Presser. Speed 1800 R. P. M.

No.	Plate	Name
•65115		Arm with 4448, 4449, 15404 and two 15405
4389	20887	" Dowel Pin
444 8	20887	" Oil Tube for oiling intermediate
		bearing
123E	20887	Arm Screw
65116	20906	" Shaft
•65117		" " 65116 with 16269 and 65118
3005	20888	" Bushing (back)
448C	20887	" " Set Screw
•4449	20888	" " (front)
144D	20887	" Screw
4288	20888	" Side Cover
51224W	20887	" " Thumb Screw
12403	20887	" Spool Pin and Thread Eyelet
8879	20890	" " Washer (cloth)
16267	20906	Balance Wheel (disc, power) 2 3/4 in.pul-
		ley with two 448C
16278	20906	Balance Wheel (disc, stand) 3 in. pulley,
		for 3022

No.	Plate	Name
448C	20887	Balance Wheel Set Screw
256J	20888	Clamp Stop Motion Clamp Screw
248A	20887	" " Stop Screw
2020 240k	20888	
*3023	20000	" " Washer
4933	20888	rianged busning
4500	20000	" " " " 3023 with
2022	20887	two 462C
462C	20887	Clamp Stop Motion Flanged Bushing Pin
3022	20007	" " Set Screw
೨ ೦ನವ		Clamp Stop Motion complete, Nos. 248A, 256J 2020 and 4933
4292	20903	Crank Connecting Rod with two 145E
145£	20887	
375C	20887	" " Cap Screw " " Hinge Screw
1518J	20887	ninge screw
•16812	20007	
4343	20905	Cylinder, 2 7/16 in. diam
56796	20905	Face Plate
56775		" 4343 with 2105
30773		Face Plate complete, Nos. 448C, 460C, 2107,
		2111,2127,2269,4369,56791,56796 and
164J	20387	two 233J
2107	20887	Face Plate Screw
233J	20887	" Thread Guard
65118	20888	Feed Cam and Arm Shaft Counterbalance
00110	20000	with 4350
435C	20887	Feed Cam and Arm Shaft Counterbalance
		Set Screw
3033	20890	Feed Connecting Link
375C	20887	" " Hinge Screw
1518J	20887	" " " Nut
16744	20889	" Dog, 12 teeth (16 teeth to the inch)
		for 65103
16846	20889	Feed Dog, 17 teeth (24 teeth to the inch)
		for 65103
65058	20389	" " (diagonal spiked teeth) for
		65103
6016	20889	Feed Dog Carrier
2250	20889	" "Screw
3037	20903	" Forked Connection
3750	20887	" " Hinge Screw
1513 J	20887	" " Nut
3039	20888	" Regulator
58E	20887	" " Hinge Screw
813D	20887	" Thumb Screw
65114	20906	" Rock Shaft
651,20		" " 65114 with 6016
6018	20388	" " Crank with 207F
156F	20887	" " " Position Screw
207F	20887	" " Set Screw
24586	20891	Knife without Guide (corner bent up) for
		under trimming

No.	Plate	Name
24587		Knife without Guide (corner bent up) and
		Holder (sectional) complete, for
		under trimming, Nos. 24174, 24586 and
		two 602F
65063	20891	Knife Driving Lever
65064		Knife Driving Lever complete, Nos. 104D,
		217J, 16749, 24173, 65063 and 65065
65065	20891	Knife Driving Lever Adjusting Block with
		24177
217J	20891	Knife Driving Lever Adjusting Block
		Screw
16748	20891	Knife Driving Lever Cam with two 465C
465C	20891	" " Set Screw
24170	20891	" Center Plate
24171	20891	н з н н н н сар
9 34 J	20891	" " " " " " Screw
756D	20891	" " " " " Screw
16749	20891	" " Fork
16750	20891	" " Cover
233J	20887	" " " " Screw
24173	20891	" " " Swivel
104D	20891	" " " " Screw
16751	20892	" " Plate
16752	20892	" " " Holder
1346D	20892	" " " " Screw
50027F	20892	" " " Screw
24174	20892	" Holder
1098C	20892	" " Adjusting Screw
886C	20892	" " " Binding
		Screw
24175	20892	Knife Holder Bushing
16753	20892	" " Position Spring
24177	20892	" " " Stud
24188		" Regulator, Nos. 886C and 1098C
50998K	20892	" " Screw
1097F	20892	" Stop Screw
602F	20891	" Screw
65119	20903	Needle Bar (hollow)
•304 5	20890	" Connecting Link
56773		" " " 3045 with 2052
377C	20887	" " " Hinge Screw
1518 J	20887	" " " " Nut
2052	20893	" " Stud with 1550
155C	20893	" " " Set Screw
290E	20893	" Screw Bushing
16813	20893	" Clamp with 196F
16814		Needle Clamp complete, Nos. 665J, 16813 and
		16815
196F	20893	Needle Clamp Screw
16815	20893	" Thread Guide
665J	20893	" " " Screw
•6022	20888	Oscillating Rock Shaft with 4784

No.	Plate	Name	31 -	77.000	Name
16806		Oscillating Rock Shaft complete, Nos. 6022	No.	Plate 20895	Roller Ball
		and 65131	16232		" " Retaining Nut
65130	20888	Oscillating Rock Shaft Hinge Pin	17680	20895	" Screw
65131		" " " " 65130	5055 3 C	20895	" Nut
00101		with 1513J	1528J	20895	Roller, 1 1/4 in. diam., 7/32 in.face,
1513J	20893	Oscillating Rock Shaft Hinge Pin Nut	51860	20894	coarse (ball bearing) complete, Nos.
4784	20893	" " " 011 Pad (felt)			1528J,1766C,50553C and twenty-four
16754	20905	" Shaft			
•6056	20893	" Crank with 460C and		-000	Roller Arm
0000	20000	1813	16230	20895	" " Adjusting Screw
6024	20893	Oscillating Shaft Crank with 1813 and	440F	20895	" " Nut
0054	20000	two 462C	1547J	20895	
2049	20893	Oscillating Shaft Crank Pin	4282	20895	" " Bracket " " Screw Center
1813	20893	" " Roller and Stud.	316F	20895	" " " Nut
460C	20893	" " Set Screw for	1547J	20895	
	20000		2205	20895	" " Lock Spring
462C	20887	6056 Oscillating Shaft Crank Set Screw for	176J	20895	" " " Nut
4020	20001	-	15 4 9J	20895	2440
3054	20903	6024	65041	20894	Roller Presser (ball bearing) complete,
52016	20890	Presser Bar			1 1/4 in.coarse roller, Nos. 176J,
689C	20893	" " Lifter" " " Screw			440F,1549J,2205,4282,16230,51860,
1520J	20893				two 316F and three 1547J
5608	20890	" Nut	190J	20895	Roller Presser Screw
453C	20893	" Lifting Bracket with 453C	2073	20896	Shuttle Bobbin
290E	20893	" " Set Screw	2211	20897	" Retaining Spring " " Rivet
3058	20890	" Screw Bushing	2212	20897	VIAGOTT
2308	20890	" Spring (heavy)	•6058		" Body with 398E,2082,2084,2211
2070	20893	" " (light)			and two 2212
	-	" Washer	•15458		Shuttle Cover
262J	20893	Pressure Regulating Thumb Screw	125017		" 15458 with 112E,486H,2078,
1987	20894	Roller, 1 1/4 in.diam., coarse, with 386D			2080,2086 and 2090
1070		and 1528J, for 16755	2076	20896	Shuttle Cover Hinge Pin
1932		Roller, 1 1/4 in.diam., fine, with 386D and	2078	20897	" Delivery Eye Thread Guard
3,6000	00005	1528J, for 65046	2080	20897	KIVEC
16098	20895	Roller Arm	2082	20897	ABTU Phing
440F	20895	" Adjusting Screw	398E	20897	DCI'BW
1547J 4282	20895 20895	1940-1	2084	20897	Steady Pin
	20895	" Bracket	466H		Tension vegoracing pores
316F 1547J	20895	" " Screw Center	2086	20897	Spring
2205	20895	" " Nut	3090	20897	Flate
2205 17 6J	20895	" Lock Spring	112E	20897	DOTOW
1549J	20895	" " " Screw	16892	20896	Shuttle (high point) complete, Nos. 2073,
16755	20894	" " Nut			2076,6058 and 125017
10/33	20034	Roller Presser complete, 1 1/4 in.coarse	6029	20897	Shuttle Driver and Feed Lifting Cam
		roller, Nos. 176J, 440F, 1549J, 1987,	2049	20893	Pin.
		2205,4282,16098,two 316F and three	16816	20896	" Race
goen	00 00E	1547J	50037F		" Screw
386D 1528J	20895 20895	Roller Screw	16756		Ring
65046	20895	" Nut	16757	20896	" " 16756 with 65059 and
00040	ದುಂತ4	Roller Presser complete, 1 1/4 in. fine			two 767J
		roller, Nos. 176J, 440F, 1549J, 1932,	16688		Shuttle Race Ring Cover
		2205,4282,16098,two 316F and three	16689	20897	" " " 16688 with 16242
		1547J			and two 725J

	7 1.44	No
No.	Plate	Name
	20897	Shuttle Race Ring Cover Latch
725,7	20895	" " Screw
50250J	20895	" " Screw
175J	20895	Screw
65059	20896	" Thread Protector
767J	20897	Screw.
2102	20898	Tension Disc
1560C	20898	" Regulating Thumb Nut
4369	20898	Releaser
2269	20898	Hinge Pin
600C	20898	Screw Stud
16202		" " 600C with 1560C
448C	20887	" Set Screw
2103	20898	spring
2105	50898	Thread Guard
56791		Tension complete, Nos. 2103, 2124, 16202 and
		two 2102
2113	20898	Thread Retaining Disc with 2113
2113	20898	Steady Pin
2114	20898	spring
2115	20898	Stud
460C	20893	Set Screw
2111	50898	Thread Retainer Guide complete, Nos. 2112,
		2114 and 2115
•16269		Thread Take-up Cam
16270	20888	" " 16269 with 4460
3012	20898	" " Pin
446C	20898	" Set Screw
*3072	20898	" Lever with 1819
56855		" " 3072 with 1088C
1088C	20898	" " Hinge Screw
1819	20898	Roller and Stud
2124	20898	Spring
2127	20898	" Regulator Plate
233J	20887	" " Ad-
		justing Screw
65102		Throat Plate
65103	20889	Throat Plate complete, for 16744, 16848
		and 65058, Nos. 65102, 65104 and two
		238D
65104	20889	Throat Plate Needle Hole Strip
238D	20889	Screw
33 5D	20889	screw
6 5066		Trimming Attachment (adjustable) com-
		plete, Nos. 1097F, 16751, 16753, 24170,
		24175,24188,24587,50998K,65064,two
	٠	each 756D,24171 and four 934J
6053	20906	Drip Pan
•15404		Trade Mark
15405		" Rivet

MACHINE BASE

No.	Plate	Name
7169	20905	Machine Base with four each 6055,51070E
		and wood screws 1 in. No. 12
51070E	20901	Machine Bolt with 51581E, to secure ma-
		chine to base
51581£	20901	Machine Bolt Nut
6055	20901	" " Washer

ACCESSORIES

ma-
• • •
• • •

BOBBIN WINDERS

BOBBIN WINDER

(SWINGING AUTOMATIC, LEFT HAND)

No.	Plate	Name
16271	20900	Base
27321	20902	Frame
50356D	20902	" Hinge Screw
1620J	20902	" " Nut
27322	20902	" Spring
27541	20900	Pulley
27305	20901	Spindle
27306	20901	Spool Pin
27307	20900	" Stand
27308	20900	Spool Stand complete, Nos. 418E, 1562J, 2106
		10141,11241,27306,27307 and two
		each 2455 and wood screws 1 in. No.
		10
11241	20900	Spool Washer (cloth)
27326	20902	Stop Latch
35D	20902	" " Hinge Screw
2455	20901	Tension Disc

No.	Plate	Name
15 62J	20901	Tension Regulating Thumb Nut
418E	20901	" Screw Stud
10141	20901	" Spring
2106	20901	" Thread Guide
16272	20900	Bobbin Winder, Nos. 35D, 1620J, 16271, 27305, 27321, 27322, 27326, 27541, 50356D and two wood screws 1 in. No. 7 F.H
16273		Bobbin Winder (swinging automatic, left hand) complete, Nos.16272 and 27308

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

No.	Plate	Name
27540	20900	Base
15072	20901	Bobbin Position Pin
27302	20902	Frame
50356D	20902	" Hinge Screw
1620J	20902	" Nut
27303	20901	" Spring
27541	20900	Pulley
•27849		Spindle
27538	20901	" 27849 with 15072,27850 and 41828.
•27850		" Collar
41828	20901	" " Pin
27306	20901	Spool Pin
150534	20900	" Stand
150535	20900	Spool Stand complete, Nos. 418E, 1562J, 2106
		10141,11241,27306,150534,two each
		2455 and wood screws 1 in.No.10
11241	20900	Spool Washer (cloth)
27312	20902	Stop Latch
35D	20902	" " Hinge Screw
2455	20901	Tension Disc
1562J	20901	" Regulating Thumb Nut
418E	20901	" Screw Stud
10141	20901	" Spring
2106	20901	" Thread Guide
27647	20900	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303,
		27312,27538,27540,27541,50356D and
		two wood screws 1 in. No. 7
150536		Bobbin Winder (swinging automatic, right hand) complete, Nos. 27647 and 150535
		imme, compression and record

FOOT LIFTER PARTS

No.	Plate	Name
6439		Chain, 36 in. to 45 in., with 56864 and
		56865
No	te: W	en ordering 6439, state length required.
4879	20904	Chain Connecting Link for 4885
56864	20904	" Hook (large)
56865	20904	" (small)
7170	20905	Lifting Lever
802D	20904	" Hinge Screw
16659	20903	" Spring
5608	20890	Presser Bar Lifting Bracket with 453C
453C	20893	" " " Set Screw
5613	20904	Tension Releaser Pin
4881	20906	Treadle
4882	20904	" Shaft
4883	20904	" Spring
4884	20906	" Stand
4885	20906	Treadle complete, Nos. 4879, 4881 to 4884
2500		and two wood screws 1 in. No. 16
6344		Foot Lifter complete, Nos. 802D, 4885, 5608, 6439,7170 and 16659

KNEE LIFTER PARTS

No.	Plate	Name
7170	20905	Lifting Lever
802D	20904	" " Hinge Screw
16659	20903	" " Spring
6333	20906	Pitman
5608	20890	Presser Bar Lifting Bracket with 453C
453C	20893	" Set Screw
2763	20905	Rock Shaft
6334	20905	" Hanger with two wood screws 1
		in. No. 10
16646	20905	Rock Shaft Knee Arm
16647		Rock Shaft Knee Arm complete, Nos. 2766,
		2767 and 16646
2766	20905	Rock Shaft Knee Arm Hub with 3560
356C	20901	" " " " Set Screw
2767	20905	" " " Plate with 356C
356C	20901	" " " Set Screw
6337	20905	" " Lifting Bracket with two 3560
6338	20905	" " " Hook
356C	20901	# " " " Set Screv
2770	20905	" Stop Dog with 356C
356C	20901	" " Set Screw

No.	Plate	Name
6339	20905	Rock Shaft complete, Nos. 2763, 2770, 6337,
		6338,16647 and two 6334
5613	20904	Tension Releaser Pin
6330		Knee Lifter complete, Nos. 802D, 5608, 6333, 6339,7170 and 16659

THREAD UNWINDER

FOR ONE SPOOL

No.	Plate	Name
225259	8405	Spool Rest with 201018C
150203	8405	" " Cushion (felt)
225388	8405	" " Rod
2003830	20901	" " Set Screw
201018C	20901	" Set Screw
202490	8405	" Stand with 2003830
225391	8405	Thread Guide
201696J	20901	" Lock Nut
225326	20904	" Position Cup
225324	8405	" Rod with 208E and 225322
208E	20901	" " Screw
225322	20901	" " Washer
225260	8405	Thread Unwinder complete, Nos. 150203,
		201696J,202490,225259,225324,225326
		225388,225391 and three wood screws
		7/3 in. No. 12
27739	8405	Thread Cone (wood) for large cones
225390	8405	" Holder, for inverted cones
No	te: No:	3. 27739 and 225390 are used with, but not
	includ	ded in 225260.

SINGER Needles should be used in SINGER Machines These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

NUMERICAL LIST OF PARTS

No.	Plate	Name
35D	20902	Bobbin Winder Stop Latch Hinge Screw, for
		16272 and 27647
58E	20887	Feed Regulator Hinge Screw
104D	20891	Knife Driving Lever Fork Swivel Screw,
112E	20897	for 65064
1166	20037	125017
123E	20887	Arm Screw
144D	20887	" Shaft Screw
145E	20887	Crank Connecting Rod Cap Screw, for 4292.
155C	20893	Needle Bar Connecting Stud Set Screw, for 2052
156F	20887	Feed Rock Shaft Crank Position Screw
16 4 J	20887	Face Plate Screw
175J	20895	Shuttle Race Ring Screw
176J	20895	Roller Arm Lock Spring Screw, for 16755,
		65041 and 65046
190J	20895	Roller Presser Screw
· 196F	20893	Needle Clamp Screw, for 16813
207F	20887	Feed Rock Shaft Crank Set Screw, for 6018
208E	20901	Thread Unwinder Thread Guide Rod Screw, for 225324
217J	20891	Knife Driving Lever Adjusting Block
0050	00000	Screw, for 65064
225C 233J	20889	Feed Dog Screw
233J	20887 20887	Face Plate Thread Guard Screw, for 56775
233J	20887	Knife Driving Lever Fork Cover Screw Thread Take-up Spring Regulator Plate
8000	20007	Adjusting Screw
238D	20889	Throat Plate Needle Hole Strip Screw, for 65103
248A	20887	Clamp Stop Motion Clamp Stop Screw, for 3022
256J	20888	Clamp Stop Motion Clamp Screw, for 3022.
262J	20893	Pressure Regulating Thumb Screw
290E	20893	Needle Bar Screw Bushing
290E	20893	Presser Bar Screw Bushing
316F	20895	Roller Arm Bracket Screw Center, for 16755,65041 and 65046
335D	20889	Throat Plate Screw
356C	20901	Rock Shaft Knee Arm Hub Set Screw.for
0000	20001	2766
356C	20901	Rock Shaft Knee Plate Set Screw, for 2767
356C	20901	" " Lifting Bracket Hook Set
		Screw, for 6337
356C	20901	Rock Shaft Stop Dog Set Screw, for 2770.
375C	20887	Feed Connecting Link Hinge Screw
375C	20887	" Forked Connection Hinge Screw
375C	20887	Crank Connecting Rod Hinge Screw

No.	Plate	Name	No.	Plate	Name
377C	20887	Needle Bar Connecting Link Hinge Screw	1518J	20887	Crank Connecting Rod Hinge Screw Nut
386D	20895	Roller Screw, for 1932 and 1987	1518J	20887	Feed Connecting Link Hinge Screw Nut
398E	20897	Shuttle Main Spring Screw, for 6058	1518J	20887	" Forked Connection Hinge Screw Nut
418E	20901	Bobbin Winder Tension Screw Stud, for 27308 and 150535	1518J	20887	Needle Bar Connecting Link Hings Screw Nut
435C	20887	Feed Cam and Arm Shaft Counterbalance	1520J	20893	Presser Bar Lifter Screw Nut
		Set Screw, for 65118			Roller Screw Nut, for 1932, 1987 and 51860
440F	20895	Roller Arm Adjusting Screw, for 16755,	1528J	20895	" Arm Adjusting Screw Nut, for 16755
		65041 and 65046	15 4 7J	20895	65041 and 65046
446C	20898	Thread Take-up Cam Set Screw, for 16270	35401	00005	Roller Arm Bracket Screw Center Nut, for
448C	20887	Arm Shaft Bushing (back) Set Screw	15 4 7J	20895	16755,65041 and 65046
448C	20887	Balance Wheel Set Screw, for 16267	15 4 9J	20895	Roller Arm Lock Spring Screw Nut, for
448C	20887	Tension Screw Stud Set Screw, for 56775	10420	20000	16755,65041 and 65046
453C	20893	Presser Bar Lifting Bracket Set Screw,	1560C	20898	Tension Regulating Thumb Nut, for 16202.
		for 5608	1562J	50307	Bobbin Winder Tension Regulating Thumb
460C	50853	Oscillating Shaft Crank Set Screw, for	10020	20001	Nut, for 27308 and 150535
		6056,	1620J	20902	Bobbin Winder Frame Hinge Screw Nut, for
460C	20893	Thread Retaining Stud Set Screw, for	10200	20002	16272 and 27647
		56775	1768C	20895	Roller Ball Retaining Nut, for 51860
462C	20887	Clamp Stop Motion Flanged Bushing Set	1813	20893	Oscillating Shaft Crank Roller and Stud,
		Screw, for 4933	1010	2200	for 6024 and 6056
462C	20887	Oscillating Shaft Crank Set Screw, for	1819	20898	Thread Take-up Lever Roller and Stud, for
		6024			3072
465C	20891	Knife Driving Lever Cam Set Screw, for	1932		Roller, 1 1/4 in.diam., fine with 386D and
		16748			1528J, for 65046
466H	20897	Shuttle Tension Regulating Screw, for	1987	20894	Roller, 1 1/4 in.diam., coarse with 386D
		125017			and 1528J, for 16755
600C	20898	Tension Screw Stud, for 16202	2020	20888	Clamp Stop Motion Clamp Washer, for 3022
602F	20891	Knife Screw, for 24587	2022	20887	" " Flanged Bushing Pin
665J	20893	Needle Clamp Thread Guide Screw, for	2049	20893	Oscillating Shaft Crank Pin
		16814	2049	20893	Shuttle Driver and Feed Lifting Cam Pin.
689C	20893	Presser Bar Lifter Screw	2052	20893	Needle Bar Connecting Stud with 155C, for
725J	20895	Shuttle Race Ring Cover Latch Screw, for			56773
DEAD	00.001	16689	2070	20893	Presser Bar Spring Washer
756D	20891	Knife Driving Lever Center Plate Screw,	2073	20896	Shuttle Bobbin, for 16892
2027	00000	for 65066	2076	20896	" Cover Hinge Pin, for 16892
767J	20897	Shuttle Race Ring Thread Protector Screw for 16757	2078	20897	" Delivery Eye Thread Guard, for
802D	20904	Lifting Lever Hinge Screw, for 6330 and			125017
0020	20904	6344	20 80	20897	Shuttle Delivery Eye Thread Guard Rivet,
818D	20887	Feed Regulator Thumb Screw			for 125017
886C	20892	Knife Holder Adjusting Screw Binding	2082	20897	Shuttle Main Spring, for 6058
0000	ಹಿರಿರುವ	Screw, for 24188	2084	20897	Bleady Fin, 101 0000
9 34 J	20891	Knife Driving Lever Center Plate Cap	2086	20897	Tension Spring, for 125017
VO10	20001	Screw, for 65066	2090	20897	riace, for incorr.
1088C	20898	Thread Take-up Lever Hinge Screw, for	2102	20898	Tension Disc, for 56791
10000	20000	56855	2103	20898	" Spring, for 56791
1097F	20892	Knife Holder Stop Screw, for 65066	2105	20898	Thread Guard, 101 30790
1098C	20892	" Adjusting Screw, for 24188.	2106	20901	Bobbin Winder Tension Thread Guide, for
1346D	20892	" Driving Lever Plate Holder Screw		00000	27308 and 150535
1513J	20893	Oscillating Rock Shaft Hinge Pin Nut,	2107	20887	Face Plate Thread Guard, for 56775 Thread Retainer Guide complete, Nos. 2112,
20200	20000	for 65131	3111	20898	2114 and 2115, for 56775
					SILE SIN SILO, TOI COTTO

No.	Plate	Name	No.	Plate	Name
2112	20898	Thread Retaining Disc with 2113, for 2111	4881	20906	Treadle, for 4885
2113	20898	" " Steady Pin, for	4882	20904	" Shaft, for 4885
2110	20000	2112	4883	20904	" Spring, for 4885
2114	20898	Thread Retaining Spring, for 2111	4884	20904	* Stand, for 4885
2115	20898	" Stud, for 2111	4885	20906	Treadle complete, Nos. 4879, 4881 to 4884
2124	20898	" Take-up Spring, for 56791	4003	20000	and two wood screws 1 in. No. 16,
2127	20898	" " Regulator Plate,			for 6344
20201	20000	for 56775	4933	20888	Clamp Stop Motion Flanged Bushing 3023
2205	20895	Roller Arm Lock Spring, for 16755,65041	4000	20000	with two 462C, for 3022
NACO	20000	and 65046	5608	20890	Presser Bar Lifting Bracket with 453C,
2211	20897	Shuttle Bobbin Retaining Spring, for 6058	0000	20000	for 6330 and 6344
2212	20897	" " Rivet,	5613	20904	Tension Releaser Pin
NA 48	1,000	for 6058	6016	20889	Feed Dog Carrier, for 65120
2269	20898	Tension Releaser Hinge Pin, for 56775	6018	20888	" Rock Shaft Crank with 207F
2308	20890	Presser Bar Spring (light)	*6022	20888	Oscillating Rock Shaft with 4784, for
2455	20901	Bobbin Winder Tension Disc, for 27308 and	COLL	20000	16806
~100	2000	150535	6024	20893	Oscillating Shaft Crank with 1813 and
2763	20905	Rock Shaft, for 6339	0054	20000	two 462C
2766	20905	" Knee Arm Hub with 356C, for	6029	20897	Shuttle Driver and Feed Lifting Cam
2.00	Боссо	16647	6053	20906	Drip Pan
2767	20905	Rock Shaft Knee Plate with 356C, for	6055	20901	Machine Bolt Nut Washer, for 7169
	20000	16647	*6056	20893	Oscillating Shaft Crank with 460C and
2770	20905	Rock Shaft Stop Dog with 356C, for 6339.	6006	ಶರಿಂತವ	1813
3005	20888	Arm Shaft Bushing (back)	•6058		Shuttle Body with 398E,2082,2084,2211
3013	20898	Thread Take-up Cam Pin	5000		and two 2212, for 16892
3022		Clamp Stop Motion complete, Nos. 248A, 256J	. 6330		Knee Lifter complete, Nos. 802D, 5608, 6333,
		2020 and 4933	. 0300		6339,7170 and 16659
•3023		Clamp Stop Motion Flanged Bushing, for	6333	20906	Pitman, for 6330
		4933	6334	20905	Rock Shaft Hanger with two wood screws 1
3033	20890	Feed Connecting Link	3001	20000	in. No. 10, for 6339
3037	20903	" Forked Connection	6337	20905	Rock Shaft Lifting Bracket with two 356C
3039	20888	" Regulator			for 6339
•3045	20890	Needle Bar Connecting Link, for 56773	6338	20905	Rock Shaft Lifting Bracket Hook, for
3054	20903	Presser Bar			6339
3056	20890	" Spring (heavy)	6339	20905	Rock Shaft complete, Nos. 2763, 2770, 6337,
•3072	20898	Thread Take-up Lever with 1819, for 56855			6338,16647 and two 6334, for 6330
4282	20895	Roller Arm Bracket, for 18755,65041 and	6344		Foot Lifter complete, Nos. 802D, 4885, 5608,
		65046			6439,7170 and 16659
4288	20888	Arm Side Cover	6439		Chain, 36 in. to 45 in. with 56864 and
4292	20903	Crank Connecting Rod with two 145E			56865, for 6344
4343	20905	Face Plate, for 56796	7169	20905	Machine Base with four each 6055,51070E
4347	20899	Wrench, for 1513 and 1518 (Accessories).			and wood screws 1 in. No. 12
4369	20898	Tension Releaser, for 56775	7170	20905	Lifting Lever, for 6330 and 6344
4389	20887	Arm Dowel Pin	8879	20890	Arm Spool Pin Washer (cloth)
4448	20887	" Oil Tube, for oiling intermediate	8908	20899	Wrench, for 1520 (Accessories)
		bearing, for 65115	10141	20901	Bobbin Winder Tension Spring, for 27308
•444 9	20888	Arm Shaft Bushing (front) for 65115			and 150535
4784	20893	Oscillating Rock Shaft Oil Pad (felt)	11241	20900	Bobbin Winder Spool Washer (cloth) for
		for 6022			27308 and 150535
4822	20899	Wrench, for 1528,1547 and 1549 (Accesso-	12403	20887	Arm Spool Pin and Thread Eyelet
		ries)	15072	20901	Bobbin Winder Bobbin Position Pin for
4879	20904	Chain Connecting Link, for 4885			27538


No.	Plate	Name	No.	Plate	Name
•15404		Trade Mark, for 65115	16816	20896	Shuttle Race
15405		" " Rivet, for 65115	16846	20889	Feed Dog, 17 teeth (24 teeth to the inch)
•15458		Shuttle Cover, for 125017			for 65103
16098	20895	Roller Arm, for 16755 and 65046	16892	20896	Shuttle (high point) complete, Nos. 2073,
16202		Tension Screw Stud 600C with 1560C, for			2076,6058 and 125017
40000		56791	24170	20891	Knife Driving Lever Center Plate, for
16230	20895	Roller Arm, for 65041			65066
16232	20895	" Ball, for 51860	24171	20891	Knife Driving Lever Center Plate Cap, for
16242	20897	Shuttle Race Ring Cover Latch, for 16689			65066
16267	20906	Balance Wheel (disc, power) 2 3/4 in.	24173	20891	Knife Driving Lever Fork Swivel, for
		pulley with two 448C			65064
•16269		Thread Take-up Cam, for 16270 and 65117.	24174	20892	Knife Holder, for 24587
16270	20888	" " 16269 with 446C	24175	20892	" Bushing, for 65066
16271	20900	Bobbin Winder Base, for 16272	24177	20892	Position Stud, for 65065
16272	20900	" Nos.35D,1620J,16271,27305,	24188		" Regulator, Nos. 886C and
		27321,27322,27326,27541,50356D and			1098C, for 65066
		two wood screws 1 in. No. 7 F.H.,	24 586	20891	Knife without Guide (corner bent up) for
		for 16273			under trimming, for 24587
16273		Bobbin Winder (swinging automatic, left	24 587		Knife without Guide (corner bent up) and
		hand) complete, Nos. 16272 and 27308.			Holder (sectional) complete, for un-
16278	20906	Balance Wheel (disc, stand) 3 in. pulley			der trimming, Nos. 24174, 24586 and
		for 3022	0,000	00000	two 602F, for 65066
16646	20905	Rock Shaft Knee Arm, for 16647	26026	20899	Screw Driver (machine) Accessories
16647		Rock Shaft Knee Arm complete, Nos. 2766,	26485	20899	(SENICLE CHISTOH) ACCESSO-
		2767 and 16648, for 6339	27302	20902	ries Bobbin Winder Frame, for 27647
16659	20903	Lifting Lever Spring, for 6330 and 6344.	27302 27303	20902	12 Mar 18 "
16688		Shuttle Race Ring Cover, for 16689	27305 27305	20901	Dpring, for another
16689	20897	" " " 16688 with 16242	27306	20901	" Spindle, for 16272 " Spool Pin, for 27308 and
		and two 725J	21000	ECOCT.	150535
16744	20889	Feed Dog, 12 teeth (16 teeth to the inch)	27307	20900	Bobbin Winder Spool Stand, for 27308
		for 65103	27308	20900	Bobbin Winder Spool Stand complete, Nos.
16748	20891	Knife Driving Lever Cam with two 465C			418E,1562J,2106,10141,11241,27306,
16749	20891	FORK, 10F 00004			27307 and two each 2455 and wood
16750	20891	" " Cover			screws 1 in. No. 10, for 16273
16751 16752	20892 20892	" " Plate, for 65066	27312	20902	Bobbin Winder Stop Latch, for 27647
16753	20892	" " " Holder " Holder Position Spring, for 65066.	27321	20902	" Frame, for 16272
16754	20905	Oscillating Shaft	27322	20902	" " Spring, for 16272
16755	20894	Roller Presser complete, 1 1/4 in.coarse	27326	20902	" Stop Latch, for 16272
10700	2000-	roller, Nos. 176J, 440F, 1549J, 1987,	27538	20901	" Spindle 27849 with 15072,
		2205,4282,16098,two 316F and three			27850 and 41828, for 27647
		1547J	27540	20900	Bobbin Winder Base, for 27647
16756		Shuttle Race Ring, for 16757	27541	20900	" Pulley, for 16272 and 27647
16757	20896	" " 16756 with 65059 and	27647	20900	" Nos.35D,1620J,27302,27303,
20.0.	20000	two 767J			27312,27538,27540,27541,50356D and
16806		Oscillating Rock Shaft complete, Nos. 6022	•		two wood screws 1 in. No. 7, for
		and 65131			150536
•16812		Cylinder, 2 7/16 in. diam	27739	8405	Thread Unwinder Thread Cone (wood) for
16813	20893	Needle Clamp with 196F, for 16814			large cones
16814		Needle Clamp complete, Nos. 665J, 16813 and	•27849		Bobbin Winder Spindle, for 27538
		16815	*27850		" " Collar, for 27538.
16815	20893	Needle Clamp Thread Guide, for 16814	41828	20901	" " " Pin, for
	-	· · · · · · · · · · · · · · · · · · ·			27538

No. 50027F 50037F 50250J	Plate 20892 20895 20895	Name Knife Driving Lever Plate Screw Shuttle Race Screw	No 651	-	Plate 20889	Name Throat Plate complete, for 16744, 16846
50037F	20895		001			
						and 65058, Nos. 65102, 65104 and two
	20000	" Ring Cover Screw				238D
50356D	20902	Bobbin Winder Frame Hinge Screw, for	651	Ω4	20889	Throat Plate Needle Hole Strip, for 65103
00000D	20002	16272 and 27647	651		20906	Feed Rock Shaft, for 65120
50553C	20895	Roller Screw, for 51860	•651			Arm with 4448,4449,15404 and two 15405
50998K	20892	Knife Holder Screw, for 65066	651		20906	" Shaft, for 65117
51070E	20092	Machine Bolt with 51581E, to secure ma-	•651			" " 65116 with 16269 and 65118
31070E	20501	chine to base, for 7169	651		20888	Feed Cam and Arm Shaft Counterbalance
51072E	20901	Machine Bolt with 51581E, to secure ma-	001	.10	20000	with 435C, for 65117
OLOTAE	20301	chine to table (Accessories)	651	19	20903	Needle Bar (hollow)
51224W	20887	Arm Side Cover Thumb Screw	651			Feed Rock Shaft 65114 with 6016
51581E	20901	Machine Bolt Nut, for 51070E and 51072E	651		20888	Oscillating Rock Shaft Hinge Pin, for
51860	20894	Roller, 1 1/4 in.diam., 7/32 in.face,	001		20000	65131
31000	20034	coarse (ball bearing) complete, Nos.	651	וצו		Oscillating Rock Shaft Hinge Pin 65130
		1528J,1766C,50553C and twenty-four	001			with 1513J, for 16806
		16232, for 65041	1203	ZAO.	20899	Oiler (copper plated) with 120343 (Ac-
50016	00000	Presser Bar Lifter	LOCE	7460	20000	cessories)
52016	20890		1203	217	20899	Oiler Spout, 3 1/2 in. long, for 120342
56773		Needle Bar Connecting Link 3045 with	1203	3463	20033	(Accessories)
Feage		2052	1060	יינר		Shuttle Cover 15458 with 112E,466H,2078,
56775		Face Plate complete, Nos. 448C, 460C, 2107,	1250) 1 T		2080,2086 and 2090, for 16892
		2111,2127,2269,4369,56791,56796 and	1500	202	8405	Thread Unwinder Spool Rest Cushion
F4501		two 233J	1502	803	0400	(felt) for 225260
56791		Tension complete, Nos. 2103, 2124, 16202 and	1500	574	20900	Bobbin Winder Spool Stand, for 150535
		two 2102, for 56775	1505 1505		20900	Bobbin Winder Spool Stand complete, Nos.
56796		Face Plate 4343 with 2105, for 56775	1500	000	20500	418E,1562J,2106,10141,11241,27306,
56855		Thread Take-up Lever 3072 with 1088C				150534, two each 2455 and wood
56864	20904	Chain Hook (large) for 6439				screws 1 in. No. 10. for 150536
56865	20904	" (small) for 6439	150	-7 0		Bobbin Winder (swinging automatic, right
65041	20894	Roller Presser (ball bearing) complete,	130	000		hand) complete, Nos. 27647 and 150535
		1 1/4 in.coarse roller, Nos. 176J,	200	383C	20901	Thread Unwinder Spool Rest Rod Set Screw
		440F,1549J,2205,4282,16230,51860,	2004	0000	20301	for 202490
		two 316F and three 1547J	2011	018C	20901	Thread Unwinder Spool Rest Set Screw, for
65046	20894	Roller Presser complete, 1 1/4 in.fine	201	0130	20301	225259
		roller, Nos. 176J, 440F, 1549J, 1932,	003	696J	20901	Thread Unwinder Thread Guide Lock Nut,
		2205,4282,16098,two 316F and three	201	OSOO	20301	for 225260
		1547J			2405	Thread Unwinder Spool Stand with 200383C
65058	20889	Feed Dog (diagonal spiked teeth) for	202	490	8405	
		65103				for 225260
65059	20896	Shuttle Race Ring Thread Protector, for	225	259	8405	Thread Unwinder Spool Rest with 201018C,
		16757				for 225260
65063	20891	Knife Driving Lever, for 65064	225	260	8405	Thread Unwinder complete, Nos. 150203,
65064		Knife Driving Lever complete, Nos. 104D,				201696J,202490,225259,225324,225326
		217J,16749,24173,65063 and 65065,				225388,225391 and three wood screws
		for 65066				7/8 in. No. 12
65065	20891	Knife Driving Lever Adjusting Block with	225	322	20901	Thread Unwinder Thread Guide Rod Washer,
		24177, for 65064				for 225324
65066		Trimming Attachment (adjustable) com-	225	324	8405	Thread Unwinder Thread Guide Rod with
		plete, Nos. 1097F, 16751, 16753, 24170,				208E and 225322, for 225260
		24175,24188,24587,50998K,65064,two	225	326	20904	Thread Unwinder Thread Guide Position
		each 756D,24171 and four 934J				Cup, for 225260
65102		Throat Plate, for 65103	225	388	8405	Thread Unwinder Spool Rest Rod for
						225260

No.	Plate	Name
225390	8405	Thread Unwinder Thread Cone Holder, for
		inverted cones
225391	8405	Thread Unwinder Thread Guide, for 225260.

SINGER Needles should be used in SINGER Machines These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2



4448 12403 2022 14389 2107 462 233 248 145 435 1518 156 207

PLATE 20888 - ONE - HALF SIZE




PLATE 20889 - FULL SIZE






PLATE 20890 - FULL SIZE








PLATE 20893 - FULL SIZE







PLATE 20894 - FULL SIZE











316 440 1547 1528 1549



50037 50250 725 175 1766 F












PLATE 20899 - ONE - HALF SIZE












PLATE 20905 - ONE-FOURTH SIZE

