


ACTAS



DRIVING MECHANISM

R1700..... Worm Wheel 1/6
M0508..... Stepped Screw
R0554..... Knob Screw
R0564..... Spacer
R0566..... Nut
R0568..... Flat Head Screw
R0572..... Flat Head Screw
R0579..... Set Screw
R1543..... Tapping Screw
R0580A..... Knife Lock Nut
R0624..... Stepped Shaft
R0626A..... Grease Bolt
R0630C..... Bushing

M0652..... Ball Bearing
M0656..... Snap Ring
R1500AZ... Gear Housing
R1504..... Knife Guard
R1512..... Round Knife (100mm dia.)
R1516A..... Allen Screw
R1605..... Guard pin
H0252..... Toothed Washer

SHARPENING MECHANISM

M0510.....	Flat Head Screw
M0528.....	Push Button
M0602.....	Stepped Shaft
M0620.....	Spring
R0688Z.....	Sharpening Stone


BASE & CUTTING GUIDE

S0047..... Flat Head Screw
R0432B..... Base
M0548..... Fillister Head Screw
R1557..... Bolt (long) M4×0.7
R1558..... Bolt (short) M4×0.7

R0574..... Set Scr
R0746..... Plate
L1502A..... Cutting
R1508..... Counte
R0585..... Needle
R0584A..... Shaft
R0622A..... Roller
R0683..... Need
M0690..... Wash
R0587..... Needle
R0586A..... Shaft
R0622A..... Roller
R0683..... Need
M0690..... Wash

MECHANISM

MOTOR PARTS



ew
Guide
r Blade
Bearing Complete
(long)
e Bearing
er
Bearing Complete
(short)
e Bearing
er

R0689..... Coller

MOTOR PARTS

R1510AS.... Motor Complete (110V)
R1511AS.... Motor Complete (230V)
R1541..... Cord (110V)
R1542..... Cord (230V)
R1524..... Brush Cap
R1525..... Carbon Brush
R1526P..... Instant ON/OFF Switch
R1531A..... Cord Holder
R1510RS.... Rotor Only (110V)
R1511RS.... Rotor Only (230V)

M0722..... Undulated Washer
M0724..... Washer
R3521..... Shaft
R3545..... Ball Bearing
R3523A..... Spacer
R3525..... Inverted Ring
R3544..... Snap Ring
R1658..... Spring Pin
R1750..... Worm 1/6
R1521A..... Name Plate

ACCESSORIES

R0628..... Allen Key (1.5mm)
R0798..... Spanner
R1515..... 8-Sided Knife