

CONSEW MODEL 310

PART NO.	PART NAME	PART NO.	PART NAME	PART NO.	PART NAME	PART NO.	PART NAME
1	2129001-100-C ARM BED ASSEMBLY	64	2120403-214 PRESSER SPRING, OUTER	125	9060100-006 PACKING FOR 122	156F	2120405-171 LINK FOR 179
2	2110901-151-B BELT FOG. 2	65	2120403-211 PRESSER BAR ONLY	126	2110204-012 GEAR COMPLETE	156G	2120405-177 SHAFT, LEFT FOR 156A
3	2120001-119 BELT FOG. 1	66	2120403-215 PRESSER BAR BUSHING	127A	2120404-241 VERTICAL SHAFT ONLY	156H	2120405-218 SHAFT, RIGHT FOR 156A
4	2120001-153-A BEL LEG, FRONT	67	9050100-215 SET SCREW FOR 66	127	2120404-241 VERTICAL SHAFT ONLY	157	2120405-218 SHAFT, RIGHT FOR 156A
5	2120001-153-A BEL LEG, REAR	68	2120403-210-A HINGED FOOT HOLDER	128	2110604-242 BUSHING	158	2120405-225 SOFT PLUG FOR 158
6	2110902-319 NUT FOR 6	69	2120403-220-A GUIDE FOR 72	129	2110204-243 VERTICAL SHAFT LOWER	159	2120405-232 NUT FOR 158
7	9540805-102 SET SCREW FOR NAME PLATE	70	2120403-238-A PRESSER BAR FOR 70	130	2120405-100-B BEL HINGED	160	2120405-232 NUT FOR 158
8	2110202-312-C THREAD GUIDE WITH THREE HOLES	71	2120403-239-B GUIDE FOR 72	131	2120405-100-B BEL HINGED	161	2120405-232 NUT FOR 158
9	9501101-259 SET SCREW FOR 9	72	2120403-239-B GUIDE FOR 72	132A	2120405-111-A OIL PUMP BODY	162	2120405-234 FEED REGULATOR ARM
10	2110602-313-A THREAD GUIDE, RIGHT	73	2120402-285 THREAD REGULATOR	133	2120405-163 OIL HOSE NIPPLE	163	2120405-244 FEED REGULATOR ROD
11	9540905-119 SET SCREW FOR 11, 13, ETC	74	9541104-289 SET SCREW FOR 73 & 90	134	9030100-091 WASHER FOR 130C	164	2120405-244 FEED REGULATOR ROD
12	2120402-315-B THREAD GUIDE, LEFT	75	2110403-216-A SPRING FOR 72	135	2120405-120-A SET RETURN CAM SHAFT	165	2120405-244 FEED REGULATOR ROD
13	2120402-315-B THREAD GUIDE, LEFT	76	2120403-240-B PRESSER BAR LIFTER	136	9501200-279 OIL PUMP COVER	166	2120405-244 FEED REGULATOR ROD
14	2120401-241 GUARD FOR TAKE UP LEVER	77	2120403-241-F PRESSER BAR LIFTER	137	2120405-112 OIL PUMP FILTER	167	9030100-091 WASHER FOR 168
15	9541104-241 SET SCREW FOR TAKE UP LEVER	78	2120403-242-A HINGE SCREW FOR 76B	138	2120405-115 FRAME FOR 130G	168	9541217-107 SET SCREW FOR 168
16	2120401-210-B ARM COVER PLATE COMPLETE	79	9015500-047 HINGE SCREW FOR 76B	139	2120405-115 FRAME FOR 130G	169	2120405-171 CAP SCREW FOR 168
16A	2120401-211 ARM COVER PLATE	80	2120403-251-A KNEE LIFTER BELL, CRANK COMPLETE, LEFT	140	2120405-115 FRAME FOR 130H	170	2120405-171 CAP SCREW FOR 168
16B	2120401-221-A PUSH BUTTON	81	9060100-011 RUBBER RING FOR 80	141	2120405-122 PISTON FOR 130E	171	2120405-171 CAP SCREW FOR 168
16C	2120401-222-A SPRING FOR 16B	82	2120403-254 BUSHING FOR 80	142	2120405-122 PISTON FOR 130E	172	2120405-171 CAP SCREW FOR 168
16D	9060200-007 STOP RING FOR 16B, 76B, ETC	83	2120403-254 BUSHING FOR 80	143	2120405-122 PISTON FOR 130E	173	2120405-171 CAP SCREW FOR 168
16E	9561103-223 SLEEVE FOR 16B	84	9501201-276 SET SCREW FOR 82	144	2120405-122 PISTON FOR 130E	174	2120405-171 CAP SCREW FOR 168
17	2120401-215-B GASKET FOR 16	85	9501201-276 SET SCREW FOR 82	145	2120405-122 PISTON FOR 130E	175	2120405-171 CAP SCREW FOR 168
18	2120401-181-A GASKET FOR 18	86	2120403-315 PRESSER BAR LIFTER CRANK	146	2120405-122 PISTON FOR 130E	176	2120405-171 CAP SCREW FOR 168
19	2120401-220 FACE COVER PLATE COMPLETE	87	9501201-276 SET SCREW FOR 82	147	2120405-122 PISTON FOR 130E	177	2120405-171 CAP SCREW FOR 168
20A	2120401-220-A CLAMP FOR 20 & 45	88	9015500-049 HINGE SCREW FOR 88	148	2120405-122 PISTON FOR 130E	178	2120405-171 CAP SCREW FOR 168
21	9561103-222-A SET SCREW FOR 20	89	2120403-411-A THREAD TENSION RELEASE	149	2120405-122 PISTON FOR 130E	179	2120405-171 CAP SCREW FOR 168
22	2120401-224 PLUG FOR SCREW HOLE	90	2120403-412 ADJUST PLATE FOR TENSION	150	2120405-122 PISTON FOR 130E	180	2120405-171 CAP SCREW FOR 168
24	2120404-119 PLUG FOR SCREW HOLE	91	2120403-413-A SET SCREW FOR 91 & 173	151	2120405-122 PISTON FOR 130E	181	2120405-171 CAP SCREW FOR 168
26	9540905-141 TENSION COMPLETE	92	9501201-276 SET SCREW FOR 91 & 173	152	2120405-122 PISTON FOR 130E	182A	2120405-251-D FEED LIFTING BELL ARM COMPLETE
27A	2120202-350-F CHECK SPRING	93	2120403-222 KNEE LIFTER BELL CRANK, RIGHT	153	2120405-122 PISTON FOR 130E	182B	2120405-251-D FEED LIFTING BELL ARM COMPLETE
27B	2120202-355-A TENSION SPRING	94	9015500-048 HINGE SCREW FOR 93	154	2120405-122 PISTON FOR 130E	183	2120405-251-D FEED LIFTING BELL ARM COMPLETE
27C	2120202-359 TENSION SPRING	95	9015500-048 HINGE SCREW FOR 93	155	2120405-122 PISTON FOR 130E	184	2120405-251-D FEED LIFTING BELL ARM COMPLETE
27D	2120202-366 BATCHET FOR 27B	96	9015500-049 HINGE SCREW FOR 95	156	2120405-122 PISTON FOR 130E	185	2120405-251-D FEED LIFTING BELL ARM COMPLETE
27E	2120202-368 SET SCREW FOR 27B	97	9015500-049 HINGE SCREW FOR 95	157	2120405-122 PISTON FOR 130E	186A	2120405-251-D FEED LIFTING BELL ARM COMPLETE
28	2120202-381 SET SCREW FOR 27	98	9410125-100 NUT FOR 97	158	2120405-122 PISTON FOR 130E	186B	2120405-251-D FEED LIFTING BELL ARM COMPLETE
29	9501506-276 SET SCREW FOR 27	99	9410125-100 NUT FOR 97	159	2120405-122 PISTON FOR 130E	187	2120405-251-D FEED LIFTING BELL ARM COMPLETE
30	212022-111-C NEEDLE BAR ONLY	99A	2110603-331-D BRACKET FOR 99B	160	2120405-122 PISTON FOR 130E	188	2120405-251-D FEED LIFTING BELL ARM COMPLETE
31	212022-111-B THREAD GUIDE FOR 30	99B	2110603-332-A KNEE LIFTER RELEASE LEVER	161	2120405-122 PISTON FOR 130E	189	2120405-251-D FEED LIFTING BELL ARM COMPLETE
32	9540805-259 SET SCREW FOR 33	99C	2110603-334 HINGE SHAFT FOR 99B	162	2120405-122 PISTON FOR 130E	190	2120405-251-D FEED LIFTING BELL ARM COMPLETE
33	2120402-194 NEEDLE	99D	2110603-335 JOINT FOR 99E	163	2120405-122 PISTON FOR 130E	191	2120405-251-D FEED LIFTING BELL ARM COMPLETE
34	2120403-111 NEEDLE PLATE	99E	9060200-048 JOINT RING FOR 99E	164	2120405-122 PISTON FOR 130E	192	2120405-251-D FEED LIFTING BELL ARM COMPLETE
35	1110301-120 SLIDE PLATE COMPLETE	99F	2120403-048 OIL RING	165	2120405-122 PISTON FOR 130E	193	2120405-251-D FEED LIFTING BELL ARM COMPLETE
35A	9540801-119 SPRING FOR 35	99G	2120403-048 OIL RING	166	2120405-122 PISTON FOR 130E	194	2120405-251-D FEED LIFTING BELL ARM COMPLETE
35B	9540801-119 SET SCREW FOR 35A	99H	2120403-048 OIL RING	167	2120405-122 PISTON FOR 130E	195	2120405-251-D FEED LIFTING BELL ARM COMPLETE
36	2120402-511 NEEDLE BAR ARM	99I	2120403-048 OIL RING	168	2120405-122 PISTON FOR 130E	196	2120405-251-D FEED LIFTING BELL ARM COMPLETE
37	2120402-511 NEEDLE BAR BUSHING	99J	2120403-048 OIL RING	169	2120405-122 PISTON FOR 130E	197	2120405-251-D FEED LIFTING BELL ARM COMPLETE
38	9501506-276 SET SCREW FOR 42, 43, ETC	99K	2120403-048 OIL RING	170	2120405-122 PISTON FOR 130E	198	2120405-251-D FEED LIFTING BELL ARM COMPLETE
39	9501506-276 SET SCREW FOR 42, 43, ETC	99L	2120403-048 OIL RING	171	2120405-122 PISTON FOR 130E	199	2120405-251-D FEED LIFTING BELL ARM COMPLETE
40	2120405-432 NEEDLE FEED HOCK LINK	99M	2120403-048 OIL RING	172	2120405-122 PISTON FOR 130E	200	2120405-251-D FEED LIFTING BELL ARM COMPLETE
41	2120405-432 NEEDLE FEED HOCK LINK	99N	2120403-048 OIL RING	173	2120405-122 PISTON FOR 130E	201	2120405-251-D FEED LIFTING BELL ARM COMPLETE
42	2120405-432 NEEDLE FEED HOCK LINK	99O	2120403-048 OIL RING	174	2120405-122 PISTON FOR 130E	202	2120405-251-D FEED LIFTING BELL ARM COMPLETE
43	2120405-431 NEEDLE FEED HOCK ARM	99P	2120403-048 OIL RING	175	2120405-122 PISTON FOR 130E	203	2120405-251-D FEED LIFTING BELL ARM COMPLETE
44	2120405-431 NEEDLE FEED HOCK ARM	99Q	2120403-048 OIL RING	176	2120405-122 PISTON FOR 130E	204	2120405-251-D FEED LIFTING BELL ARM COMPLETE
45	9841200-456 NEEDLE FEED HOCK ARM	99R	2120403-048 OIL RING	177	2120405-122 PISTON FOR 130E	205	2120405-251-D FEED LIFTING BELL ARM COMPLETE
46	2120402-513 HINGE SHAFT FOR 47	99S	2120403-048 OIL RING	178	2120405-122 PISTON FOR 130E	206	2120405-251-D FEED LIFTING BELL ARM COMPLETE
47	1220400-513 HINGE SHAFT FOR 47	99T	2120403-048 OIL RING	179	2120405-122 PISTON FOR 130E	207	2120405-251-D FEED LIFTING BELL ARM COMPLETE
48	9060100-013 OIL SEAL FOR 47	99U	2120403-048 OIL RING	180	2120405-122 PISTON FOR 130E	208	2120405-251-D FEED LIFTING BELL ARM COMPLETE
49	2120201-254 PLUG FOR SCREW HOLE	99V	2120403-048 OIL RING	181	2120405-122 PISTON FOR 130E	209	2120405-251-D FEED LIFTING BELL ARM COMPLETE
49A	2120404-340 COLLAR COMPLETE FOR 47	99W	2120403-048 OIL RING	182	2120405-122 PISTON FOR 130E	210	2120405-251-D FEED LIFTING BELL ARM COMPLETE
50A	9531003-259 SET SCREW FOR 50	99X	2120403-048 OIL RING	183	2120405-122 PISTON FOR 130E	211	2120405-251-D FEED LIFTING BELL ARM COMPLETE
50B	9531003-259 SET SCREW FOR 50	99Y	2120403-048 OIL RING	184	2120405-122 PISTON FOR 130E	212	2120405-251-D FEED LIFTING BELL ARM COMPLETE
51	2120402-512 SET SCREW FOR 51	99Z	2120403-048 OIL RING	185	2120405-122 PISTON FOR 130E	213	2120405-251-D FEED LIFTING BELL ARM COMPLETE
52	9531102-219 OIL WICK RETAINER FOR 51	100	2120403-048 OIL RING	186	2120405-122 PISTON FOR 130E	214	2120405-251-D FEED LIFTING BELL ARM COMPLETE
53	2120405-393 SET SCREW FOR 53	101	2120403-048 OIL RING	187	2120405-122 PISTON FOR 130E	215	2120405-251-D FEED LIFTING BELL ARM COMPLETE
54	9531102-219 SET SCREW FOR 53	102	2120403-048 OIL RING	188	2120405-122 PISTON FOR 130E	216	2120405-251-D FEED LIFTING BELL ARM COMPLETE
55	2110232-130 TAKE UP LEVER CRANK COMPLETE	103	2120403-048 OIL RING	189	2120405-122 PISTON FOR 130E	217	2120405-251-D FEED LIFTING BELL ARM COMPLETE
55A	9013400-013 SET SCREW FOR 55	104	9400801-106 NUT FOR 104	190	2120405-122 PISTON FOR 130E	218	2120405-251-D FEED LIFTING BELL ARM COMPLETE
55B	9501801-276 SET SCREW FOR 55	105	2110603-331-D BRACKET FOR 99B	191	2120405-122 PISTON FOR 130E	219	2120405-251-D FEED LIFTING BELL ARM COMPLETE
55C	9501801-276 SET SCREW FOR 55	106	2110603-332-A KNEE LIFTER RELEASE LEVER	192	2120405-122 PISTON FOR 130E	220	2120405-251-D FEED LIFTING BELL ARM COMPLETE
56	2120402-02-C TAKE UP LEVER COMPLETE	107	2110603-334 HINGE SHAFT FOR 99B	193	2120405-122 PISTON FOR 130E	221	2120405-251-D FEED LIFTING BELL ARM COMPLETE
57	2120402-02-C TAKE UP LEVER COMPLETE	108	2110603-335 JOINT FOR 99E	194	2120405-122 PISTON FOR 130E	222	2120405-251-D FEED LIFTING BELL ARM COMPLETE
58A	9501801-276 SET SCREW FOR 56	109	9060200-048 JOINT RING FOR 99E	195	2120405-122 PISTON FOR 130E	223	2120405-251-D FEED LIFTING BELL ARM COMPLETE
58B	9501801-276 SET SCREW FOR 56	110	2120403-048 OIL RING	196	2120405-122 PISTON FOR 130E	224	2120405-251-D FEED LIFTING BELL ARM COMPLETE
59	2120402-150 HINGE STUD FOR 56	111	2120403-048 OIL RING	197	2120405-122 PISTON FOR 130E	225	2120405-251-D FEED LIFTING BELL ARM COMPLETE
60	9501801-276 SET SCREW FOR 58, 174, ETC	112	2120403-048 OIL RING	198	2120405-122 PISTON FOR 130E	226	2120405-251-D FEED LIFTING BELL ARM COMPLETE
61	2120203-271-A SET SCREW FOR 61	113	2120403-048 OIL RING	199	2120405-122 PISTON FOR 130E	227	2120405-251-D FEED LIFTING BELL ARM COMPLETE
62	2120203-271-A SET SCREW FOR 61	114	2120403-048 OIL RING	200	2120405-122 PISTON FOR 130E	228	2120405-251-D FEED LIFTING BELL ARM COMPLETE
63	2120403-272-A PRESSER SPRING, INNER	115	2120403-048 OIL RING	201	2120405-122 PISTON FOR 130E	229	2120405-251-D FEED LIFTING BELL ARM COMPLETE

Use only exact parts number for ordering. Be sure indicate all digits and letters as indicated in listing. Do not use position number from illustration for ordering.